

Fire Toolbox Talk

- Fire requires three elements, called the fire triangle; these area source of fuel, oxygen and a source of ignition.
- Removing any one of the three elements above removes the possibility of fire.
- Remove all flammable material such as packaging materials daily so there is no fuel.
- Do not let this build up, PAT test tools, remove flammable materials when grinding, welding etc. and NO SMOKING.
- You should have been told the site fire procedures during your induction.
- The site should have a muster point where people father for a roll call It is important
 you sign in and out of site and do not defeat these controls as in the event of a fire it
 is important to account for all those on site.
- The fire brigade need to know if there is anyone trapped who needs to be rescued or whether the building is empty.
- All sites should have a way of raising the alarm and fire extinguishers located at strategic positions. You should have been told this information at induction.

Powered By

