Extruder motor switch (or jumper if no switch) SS Relay Thermistor (RepRap Arduino MEGA Pololu Shield) GPL v3 reprap.org/wiki/RAMPS1.4 Reversing input power, and inserting stepper drivers incorrectly will destroy electronics. I2C D18 D19 Filament 0000000 0000000 000 Fan 20 000 00000 L2 35V Out 0000 GND 0000 000 5U 000 D10 000 000 AUX-4 000 Winder D16 000 Power D17 000 D23 8 D25 0000 0000 D11 D27 D29 12-35UDC In D33 + 12 V D35 D37 supply D39 - 12 V 0000 D41 00000 000 0000 D43 supply 0.0.0.0 0,0,0,0 0000 D45 AUX-3 / SPI SERVOS Blob sensor +5v D1 GND GND NC 5U Blob sensor gnd ight 2011 Johnny Russell - UltiMachine Filament sensor gnd Filament sensor +5v M1 Extruder stepper motor M2 Puller stepper motor Filament sensor input