

Tooling / Die Changeover Procedure

Standard Operating Procedure

Doc ID	SOP-PRD-005
Version	2.0
Effective Date	2026-02-01
Owner	Maintenance Department
Scope	CNC Milling (tool changeover) and Press Line (die changeover) units, all plants

1. Purpose

Standardizes the changeover sequence between product runs to minimize DT-03 changeover downtime and ensure first-article quality on restart.

2. Required PPE

- Safety glasses
- Cut-resistant gloves
- Steel-toe boots

3. Tools & Materials

- Overhead crane / die cart (for press dies)
- Torque wrench
- Tool presetter (for CNC tooling)
- Changeover checklist

4. Procedure

- 1 Confirm production schedule and pull the correct tool/die kit before the current run ends (external setup).
- 2 Bring machine to a safe stop and lockout per Safety_Guidelines before removing tooling.
- 3 Remove outgoing tool/die; inspect mounting surfaces for damage or debris.
- 4 Install incoming tool/die; torque clamps/bolts to specification in the correct sequence.
- 5 Verify tool offsets (CNC) or shut height and cushion pressure (Press) against the setup sheet.
- 6 Run first-article part(s) and inspect against drawing before releasing to full production.
- 7 Record changeover start/end time to support DT-03 downtime tracking.

5. Associated Downtime Code

Code	Description	Severity	Typical Duration
DT-03	Tooling / Die Changeover Delay	Moderate	36 min

■ **Never reach under a raised die or tool assembly that is not mechanically blocked, even momentarily.**