



Workshop Mechatronics II MERO Joshua Voll, M.Eng. Schmalkalden, 27.04.2022

Agenda

Live slicing

Guidelines

Workshop: Pen Plotter

J

Live-slicing

Cura





Agenda

Live slicing

Guidelines

Workshop: Pen Plotter


Samuel Werner



What do I have to pay attention to when designing?

Important: No radii at the bottom!


Connection to build board!



What do I have to pay attention to when designing?

Important: If possible align your drill holes in Z direction!

Connection to build board!
Align your drill holes!




Important: Be aware of the anisotropic material properties!

Connection to build board!

Align your drill holes!

Anisotropic material properties!



weak

What do I have to pay attention to when designing?

Important: Do not construct threads!


Connection to build board!

Align your drill holes!

Anisotropic material properties!

Cut threads after printing!

ā .	20 10
Gewinde	Kernlochbohrer
M 1	0,75
M 1,1	0,85
M 1,2	0,95
M 1,4	1,1
M 1,6	1,3
M 1,8	1,5
M 2	1,6
M 2,2	1,8
M 2,5	2,1
M 2,6	2,1
M 3	2,5
M 3,5	2,9
M 4	3,3
M 5	4,2
M 6	5
M 7	6
M 8	6,8
_	1



necessary hole diameter required thread

http://www.moh-computer.de

What do I have to pay attention to when designing?

Important: Holes become smaller due to the manufacturing process!


Connection to build board!

Align your drill holes!

Anisotropic material properties!

Cut threads after printing!

Design holes 0.2 mm larger!




in real: 5,8 mm



What do I have to pay attention to when designing?

Important: Do not print standard parts!

Connection to build board!
Align your drill holes!
Anisotropic material properties!
Cut threads after printing!
Design holes 0.2 mm larger!
Use standard parts!



What do I have to pay attention to when designing?

Important: Do not design areas that are too thin!

Connection to build board!

Align your drill holes!


Anisotropic material properties!

Cut threads after printing!

Design holes 0.2 mm larger!

Use standard parts!

Attention to the wall thickness!



olie 12

Guidelines

What do I have to pay attention to when designing?

Important: Do not design sharp-edged transitions!

Connection to build board!

Align your drill holes!

Anisotropic material properties!


Cut threads after printing!

Design holes 0.2 mm larger!

Use standard parts!

Attention to the wall thickness!

Round off connections!





Agenda

Live slicing

2

Guidelines

3

Workshop: Pen Plotter



Building utensils

pen	p	0	tter	b b	OX


Designation	Specification	Quantity	Manufacturer	Image
Plug-in board	MB-102 Plug-in board 830 pins60320025	1	Eckstein Komponente	The state of the s
Moto Driver	Qwiic Motor Driver	1	SparkFun	
7-Segment Serial Display Red	Thing Plus ESP32 WROOM WRL 17381	1	SparkFun	
Cable		65	Keyestudio	
lithium battery + cable		1	SparkFun	Same the latest and t
Motors	DAGU - DG01D 48:1 - Mini DC GearBox	2	SparkFun	
Power supply unit	Breadboard Power Supply TS1171	1	QITA	
base plate	305x305x15 mm	1	Holzland	
Hall effect sensor	Module magnetic detector 49E LM393TS0145	1	Eckstein Komponente	

Microswitch red	XSS-5GL13	4	amazon
Belt	T2 2mm pitch 6mm wide rubber timing belt	2m	amazon
Linear ball bearing	LMU-N6	8	Misumi
Push button	Ø 15 / length 24 [mm]	1	amazon
Shafts	d6 x 300mm	4	Misumi
Storage box		1	


- bolts and nuts:
- use standard machine screws (i.e socket head, hexagon,
 - M4 x (8, 10, 12, 16, 20, 25)
 - M5 x (10, 12, 16, 20, 25, 30)
 - M6 x (16, 20, 25, 30, 35)



Pen-Plotter




Pen-Plotter



Folie 17

Pen-Plotter





Thank you for your attention