

4.2.3 How to offset points

1. In the Point management page, select the point to be offset by selecting the check box in the Check column.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RY (degree)	RZ (degree)	Hand	UserID	ToolID	Coordinate	Coordinates
1001	☐	p1001	213.740	202.111	0.000	0.000	0.000	1	0	0	1	
1002	☐	p1002	213.740	202.111	0.000	0.000	-292.437	1	0	0	1	
1003	☐	p1003	0.000	0.000	0.000	0.000	0.000	0	0	0	1	
1004	☒	p1004	330.306	27.522	-51.791	-65.720	-189.740	1	0	0	1	
1005	☐	p1005	0.000	0.000	0.000	0.000	0.000	0	0	0	1	

2. Input the offset distances in the Offset area of the **Point** subpage.

Point

Offset

Select points before setting offset

ΔX (mm):

ΔY (mm):

ΔZ (mm):

3. Click **Offset**, and then click **check** in the confirmation window.

DRAStudio

X



Offset Local Point Done.

4. Then, the offset values are added to the selected point.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RY (degree)	RZ (degree)	Hand	UserID	ToolID	Coordinate	Coordinates
1001	☐	p1001	213.740	202.111	0.000	0.000	0.000	1	0	0	1	
1002	☐	p1002	213.740	202.111	0.000	0.000	-292.437	1	0	0	1	
1003	☐	p1003	0.000	0.000	0.000	0.000	0.000	0	0	0	1	
1004	☒	p1004	380.306	57.522	-51.791	-65.720	-189.740	1	0	0	1	
1005	☐	p1005	0.000	0.000	0.000	0.000	0.000	0	0	0	1	

5. The row is highlighted orange, indicating that the data has been changed but not saved.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RY (degree)	RZ (degree)	Hand	UserID	ToolID	Coordinate	Coordinates
1001	☐	p1001	213.740	202.111	0.000	0.000	0.000	1	0	0	1	
1002	☐	p1002	213.740	202.111	0.000	0.000	-292.437	1	0	0	1	
1003	☐	p1003	0.000	0.000	0.000	0.000	0.000	0	0	0	1	
1004	☒	p1004	380.306	57.522	-51.791	-65.720	-189.740	1	0	0	1	
1005	☐	p1005	0.000	0.000	0.000	0.000	0.000	0	0	0	1	