;Write a program that will check whether D4 bit of data at address 9030 is zero. Just check the result after the operation.

MVI A,0FFH STA 9030H; Say 9030H has ACH as its value

STC

CMC

RAL

RAL

RAL

RAL

JNC L1

MVI A,01H; If D4 is 1,1 will be displayed at 40H

OUT 40H

HLT

L1: MVI A,00H ;If D4 is 0,0 will be displayed at 40H OUT 40H

HLT