



NICHOMACHINES.COM



Content

Inserting / changing tools in drilling machine..... 3

Inserting / change of tools in spindle 4

Inserting / changing tools in drilling machine.

Change of tooling in the drilling box, loosen the screws in the spindle and take out the drills that need to be changed and securely tighten the screws again.

Detailed steps:

Loosen the screws on the drill spindle with a 3mm hexagonal socket as shown in the diagram, place the 70mm long drill bit on the bottom and secure the flat side of the drill bit with the top wire.

Upper machining unit or lower machining unit, tap up the drill bit to pop back to its original position, replacement is complete, if you want to replace another drill bit repeat steps 3-5



Inserting / change of tools in spindle

Make sure that the tools and shaft are clean, and when inserting into the tool holder, the holder needs to be cleaned.





NICHOMACHINES.COM