DRINKPRIME WATERWALA LABS PVT LTD

TITLE: DEVICE CHECKING PROCESS

1. MATERIAL REQUIRED:

S. No.	Item Name	Unit	Qty
1.	Sediment Filter Yarn	Nos	1
2.	Pre -carbon filter	Nos	1
3.	RO membrane	Nos	1
4.	FRT 450	Nos	1
5.	WIFI bot with flow sensor	Nos	1
6.	Float switch	Nos	1
7.	Solenoid Valve	Nos	1
8.	Pump – 100 GPD	Nos	1
9.	Post Carbon with Copper	Nos	1
10.	UV Filter With Choke	Nos	1

2. TOOLS REQUIRED

S. No.	Item Name	UOM	Qty.
1.	Screwdriver	No.	1
2.	Pipe Cutter	No.	1
3.	Pressure Gauge	No.	2
4.	1 liter Flow Rate measuring beaker	No.	1
5	Stop Watch	No.	1

3. ACTIVITIES

Field Return Device Categories:

- Devices are categorized into three types: Easy, Medium, and Hard.

Input Water Pressure Testing:

- Connect the field return device to an input water pressure of 1 kg for testing.

Filter Scrapping Criteria:

- Filters should be scrapped if they have worked for more than 6 months from the manufacturing date.

Flow Rate Requirements:

- Sediment and Pre-carbon flow rates should be a minimum of 1200 ml/min & above.
- RO membrane flow rate should be a minimum of 180 ml/min & above.
- FRT flow should be between a minimum of 380 ml/min & above.

Pump and Solenoid Valve (SV) Testing:

- Pump output pressure should be minimum of 60 psi & above with flow rate of 1200 ml/min.
- SV should be tested for cut off, cut in, open flow, and body clearances.

WIFI Bot Testing:

- Conduct LED indication test WRT to LED indication Chart.
- Conduct a 1-liter cut off test for the WIFI bot.
- Perform float switch cut off and cut in tests.

Filter Handling Post-Testing:

- Once device testing is complete, all "OK" filters should be drained and put back in the device.

4. SCRAP DISPOSAL INSTRUCTIONS:

Polythene Cover Disposal:

- Ensure that polythene covers are placed in their respective bins only.

Chassis Carton Box Disposal:

- Ensure that chassis carton boxes are placed in their respective bins only.

Rejected Filters & Spare materials:

- Rejected filters & spare materials should be kept in designated respective bins.

Daily Cleanliness:

- Rejected materials should be removed from the testing area daily to keep the area clean.

5. SAFETY INSTRUCTIONS:

1. Keep the materials away from the gangway.

6. CHECKS:

1. Check Chassis for dent & scratches
2. Check crimping should be perfect.

7. RESPONSIBILITY:

1. Operator

8. QC RESPONSIBILITY:

1. Line Quality person monitoring the process every 1 hour once for smooth process.
2. Allow & Not allowed Spec. & visual Photo to provided to the line & monitor the process.