TITLE: WI FOR MEMBRANE ASSEMBLY.

1. MATERIAL REQUIRED:

S.NO.	ITEM NAME	UOM	QTY.
1	MEMBRANE BOWL	No.	1
2.	MEMBRANE CAP	Nos	1
3.	MH ELBOW 1/4"(MEMBARANE ELBOW)	Nos	2
4	MEMBRANE “O-Ring”	Nos	1
	PF ELBOW 1/4" (1/4" PF TO THREAD)	Nos	1
	TEFLON TAPE	MTR	1

2. TOOLS REQUIRED:

S.NO.	ITEM NAME	UOM	QTY.
1.	Spanner	No.	1
2.	End plug	No.	1
3.	Pressure Gauge	No.	1
4	Colin	No.	1
5	Ball valve	No.	1
6	PL4 Tube	Mtr	0.5
7	Water Bin	No.	1
8	Cleaning Cloth	No.	1

3. ACTIVITIES:

3.1 Take PF ELBOW 1/4" (1/4" PF TO THREAD) & MH ELBOW 1/4"(MEMBARANE ELBOW)and wound the Teflon tape on the threaded portion with approx. 20 to 30 rounds.

3.2 insert the PUMP ELBOW 1/4" Membrane cap head thread & tighten with the help of spanner tool & make ensure without damage.

3.3 Insert the MH ELBOW 1/4"(MEMBARANE ELBOW) Membrane bowl Reject & outlet thread & tighten with the help of spanner tool & make ensure without damage.

3.4 Insert the membrane inside the bowl & close with the membrane cap assembly.

3.5 Ensure the cap is tightened properly with spanner assembly.

3.6 Check for leakage, pass the 80-90 PSI air in the inlet of the membrane cap head & close the outlet (Permeate) with End plug & close the reject outlet with ball valve

PREPARED BY	REVIEWED BY	APPROVED BY	ISSUED BY

3.7 Dip the membrane assembly in the water bin & Check for leakage.

3.8 Leak test passed, Clean the membrane and move to production line, otherwise sent for rework.

4. SCRAP DISPOSAL:

4.1 Keep the scrap in the respective bins only.

4.2 QC persons validate & certify the rejection every 2 hrs. once in the line.

5. SAFETY INSTRUCTIONS:

5.1 Keep the material away from the gang way

6. CHECKS:

6.1 Ensure that all the connections are tightened properly.

7. RESPONSIBILITY:

Operator

Quality person