

STANDARD OPERATING PROCEDURE INDUSTRIAL PLANT SAFETY & ISOLATION

Document ID: SOP-SAFE-002

Document Type: sop

Revision: Rev 2.1

Effective Date: 2026-02-01

Department: Health, Safety & Environment (HSE)

1. Mandatory Personal Protective Equipment (PPE)

All personnel entering rotating equipment areas and operating units must wear:

- Industrial safety helmet (EN 397 certified)
- Steel-toe boots with puncture-resistant soles
- High-visibility safety vest
- Safety glasses with side shields
- Heat-resistant gloves when inspecting hot surfaces

2. Emergency Isolation and Shutdown Procedure

In case of fire, bearing seizure, or catastrophic equipment vibration:

1. Depress the nearest emergency trip button immediately.
2. Evacuate non-essential personnel to the designated muster point.
3. Notify the central control room via direct radio channel 4.
4. Do not re-enter the area until cleared by the safety officer.

Document ID: SOP-SAFE-002 (Page 2)

3. Lockout/Tagout (LOTO) Procedure

Before performing any mechanical or electrical maintenance on rotating machinery:

1. Identify all electrical, hydraulic, and pneumatic energy sources.
2. Notify operations supervisor and affected shift personnel.
3. Open circuit breakers and isolate feed valves.
4. Apply standardized LOTO padlock and danger warning tag.
5. Verify zero energy state using voltage detector and manual rotation check.
6. Maintain lockout key in authorized lockbox during entire work duration.