MISH 25

HEAT RELATED ILLNESS PREVENTION

AGC CSEA Alignment

Risk Identification and Analysis

OSHA Core Element

Hazard Prevention and Control

Section Summary

Defines heat-related illness prevention measures including acclimatization, hydration, rest breaks, and emergency response procedures.

Core Values: Integrity | Honesty | Professionalism | Thoroughness

"Building projects for the client, NOT the dollar."

HEAT RELATED ILLNESS PREVENTION

Document: MISH 25	**Revision:** 2	**Effective:** 04/07/2026	**Approved:** Jeremy Thamert

AGC CSEA Alignment	OSHA Core Element
Risk Identification and Analysis	Hazard Prevention and Control

1.0 PURPOSE

To define the requirements and responsibilities for recognizing, evaluating, and controlling employee heat related illness (HRI) in the workplace. The program also ensures compliance with Occupational Safety and Health Administration/Washington Department of Occupational Safety and Health (OSHA/DOSH), and other applicable regulations.

2.0 SCOPE AND APPLICABILITY

Work areas where temperatures exceed trigger levels outlined in Table 1, when working for more than 15 minutes each hour, must follow this procedure. Heat related illness has been relocated from MISH 23, 5.7 to MISH 25. Revisions encompass new regulations set forth in WAC 296-62-095: Heat Related Illness in the Outdoor Environment. Indoor work is still included within this procedure. This procedure should be followed unless project contract requirements exceed the requirements of this section. In such case, the more stringent requirements shall be followed.

TABLE 1 – TRIGGER TEMPERATURES

AT DEW POINT OF 50■ F

Clothing/Personal Protective Equipment (PPE) Worn

Work in Direct Sun

Work in Shaded (or Indoor) Areas Standard MH Construction work/safety clothing (hard hat, 4” shirt sleeves, long pants, boots) or coveralls over light clothing

89■ F 96■ F Additional layer – coveralls - over standard MH Construction work/safety clothing 77■ F 87■ F Additional non-breathable layer - vapor barrier such as Tyvex or rubber, raingear, or other similar material 52■ F 62■ F

When near trigger temperatures are forecasted, Supervisors must check weather periodically in order to ensure these requirements are implemented when trigger levels are reached. Current data distributed by a news station, organization, or website, or similar, are suitable sources. An electronic weather station is also an acceptable method to monitor temperature.

- Supervisors must check temperature as often as necessary to ensure HRI controls are implemented at the moment trigger temperatures are reached.

Supervisors can implement the minimum requirements of this procedures and forego monitoring for temperature, at their discretion, provided the minimum requirements are met once trigger levels are reached.

3.0 EXPOSURE CONTROL METHODS

In addition to temperature, many factors can increase the risk for HRI. Factors such as humidity, radiant heat, air movement, conductive heat sources (heavy equipment), work load and duration, working in direct or shaded work

areas, types of clothing and personal protective equipment (PPE) worn, and personal factors: such as age, drinking alcohol, smoking, and/or poor diet all are contributing factors to HRI. Both Supervisors and employees need to know about these factors and seek to minimize these contributing factors whenever possible.

Supervisors can reduce Many of these factors can be controlled Facilitating acclimation to weather and worker hydration are the top two factors contributing to HRI and are factors that Supervisors can control in the following ways:

- ACCLIMATION: Adjusting work times and activities. Scheduling more strenuous work activities to be conducted during cooler parts of the day or starting work earlier to decrease the amount of time in hotter weather.
- HYDRATION: Provide and encourage consumption of water. NEVER run out of water onsite. Plan for providing at least one quart of water per worker per hour. It is acceptable to start the work shift with less water onsite, but Supervisors must pre-plan to supply water readily, in sufficient quantities.

Supervisors must ensure that employees report HRI symptoms. If an employee complains of cramps, headache, anxiety, or tingling in hands (the beginning symptoms of HRI) or signs of heavy sweating, intense thirst, dizziness, fatigue, loss of coordination, nausea, impaired judgment, loss of appetite, hyperventilation, and/or cool moist skin (serious symptoms of heat stress), Supervisors must take action immediately. If HRI symptoms are observed, take action immediately by:

- Monitor or and treat employee, as necessary. Cool down the worker by moving the worker to a shaded area or air-conditioned (vehicle or trailer) environment, removing excess clothing and boots, provide cooling cloths, etc. Encourage intake of water and closely monitor the employee.
- If symptoms do not subside and symptoms such as hot, dry skin, extremely high body temperature with a rapid pulse, or the employee falls unconscious – these are signs of heat stroke A MEDICAL EMERGENCY – GET HELP IMMEDIATELY.

4.0 TRAINING

Employees are responsible to monitor themselves for HRI, Supervisors are responsible to educate workers on HRI topics including: recognizing the symptoms of heat exposure; the importance and expectation of hydration, acclimation and reporting symptoms; personal risk factors increasing the susceptibility to HRI (age, medical conditions, un-healthy diet, and consumption of alcohol, nicotine, caffeine, and prescription drugs); removal of PPE during breaks; and emergency planning. A chart of symptoms of the progressive stages of HRI is attached.

Employees are responsible to monitor themselves and co-workers for HRI, report symptoms immediately, consume adequate amounts of water, participate in maximizing acclimation and minimizing personal risk factors.

- Supervisors must ensure they are knowledgeable with the requirements of applicable standard(s) and this procedure in order to effectively train employees.

5.0 RECORDS

Documentation of employee training: Group Training Sign In Sheet

6.0 REFERENCES

29 CFR 1910 Occupational Safety and Health Standards (OSHA)

29 CFR 1926 Safety Standards for the Construction Industry (OSHA)

WAC 296-62 Occupational Health Standards (WISHA)

WAC 296-155 Safety Standards for Construction Work (WISHA)

7.0 ATTACHMENTS

HEAT RELATED ILLNESS – KNOW THE SIGNS AND DANGERS

End of Document