



CONTROLLED ENTERPRISE DOCUMENT

TBT-05.02 | Hot Work And Welding Fire Watch

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-05.02 | Hot Work And Welding Fire Watch

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-05.02: Hot Work & Welding Fire Watch

CSI Division: Div 05 | OSHA Reference: 29 CFR 1926.352

Delivery: Mandatory for all welding, cutting, brazing, and grinding operations.

DIRECTIVE — Policy Standard

No hot work may commence without an approved MISH-F-30.1 Hot Work Permit and a dedicated Fire Watch equipped with a 20lb ABC fire extinguisher.

GENERAL ORDER — Procedure

Combustible materials within a 35-foot radius must be removed or covered with fire-retardant blankets. The Fire Watch must remain on station for a minimum of 30 minutes after the hot work concludes.

Key Hazards & Mitigation (The 'What If'):

- Sparks Dropping to Lower Levels: If welding on a mezzanine, sparks can drop through floor penetrations and ignite materials below. The 35-foot radius applies vertically as well as horizontally.
- Welding Near Flammables: If a crew needs to weld a pipe bracket near a diesel fuel tank, the tank must be drained, purged, and tested with a multi-gas meter before striking an arc.
- Fire Watch Leaves Early: If the welder finishes and the Fire Watch leaves immediately for break, a smoldering ember could ignite 15 minutes later. The 30-minute post-work watch is non-negotiable.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must physically walk the 35-foot radius with the Fire Watch to identify combustibles before signing the MISH-F-30.1 permit. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade