

See dry Box wiring
Use the cable in the IEC

IEC cable

See dry Box wiring
Use the cable in the IEC

Bolt an earth wire to the aluminium frame of the printer!!

IEC Power In

To 6p HDC

SSR Bed

To 10P HDC

Bolt earth wire to plate

- Connect to earth bolt on frame

Bolt earth wire to plate

Connect to earth bolt on frame

Aluminium mounting panel

Live  Br 18 awg silicone
Neutral  BL 18 awg silicone
Earth  Gr 18 awg silicone

Remover anodising
under star washer

make sure the shorting bars (in Purple) across the terminals are only 3 units wide
Use ring crimps on the SSR connections (4mm id)
Use a small amount of heatsink compound between SSR and Aluminium plate

