

*Solder a wire to the reset pin of both U1 and U2 and connect them togeather