



## PC-BOT 914 Bumper IR Locations Diagram

**Note:** Bumper Area IR sensors (Total of 7, but two not populated). All sensors point out horizontally, 7 IR sensors are spread out equally.



## I/O Board Wiring location



Note: Specifications may change without notice

Document Id:

Description: PC-BOT 914 Bumper IR Locations Diagram

Revision: v1.2

Date: April 27, 2007

