

T. Y. B. Tech (Electrical and Computer Engineering)

Trimester: V Subject: Microcontroller and Applications

Name: Shreerang Mhatre Class: TY
Roll No: 52 Batch: A3

Experiment No: 09

Name of the Experiment: Interfacing of Stepper motor with C8051F340.

Performed on: 31/10/2023

Submitted on: 07/11/2023

Mark
s

Teacher's Signature with date

Aim: Write C program for interfacing of Stepper motor with C8051F340 to rotate in clockwise and anticlockwise direction.

Apparatus: EPBF340 board, Stepper motor Board

Theory:

A stepper motor is known by its important property to convert a train of pulses into a precisely defined increment in the shaft position. A stepper motor is a widely used a device that translates electrical pulses into mechanical movement. In applications such as disk drivers, dot matrix printers, and robotics, the stepper motor is used for position control. Every stepper motor has a permanent magnet rotor (also called as shaft) surrounded by a stator the most common stator motors have four stator windings that are paired with a centre-tapped common as shown in the figure. This type of stator motor is commonly referred to as four phase stepper motor. The centre tap allows a change of current direction in each of two coils, when a winding is grounded, thereby resulting in polarity change of the stator. Notice that while a conventional motor shaft runs freely, the stepper motor shaft moves in a fixed repeatable increment which allows one to move it to a precise position.






Figure 8.1 Stepper motor windings

This repeatable fixed movement is possible as a result of basic magnetic theory where poles of same polarity repel and opposite attract. The direction of rotation is indicated by the stator poles. The stator poles are determined by the current sent through the wire coils A, B,C and D as shown in Figure 8.1. As the direction of current is changed, the polarity is also changed causing the reverse motion of the rotor. The stepper motor discussed here has a total of six leads: four leads representing the four stator windings and two commons for the centre tapped leads. As the sequence of power is applied to each stator winding, the rotor will rotate. There are several widely used sequences where each has a different degree of precision. The stepping sequence of excitations is as shown in Table 8.1.

Table 8.1 The stepping sequence

Windings	D		С		В		A	
Sequence in hex on Port 4	P4.7	P4.6	P4.5	P4.4	P4.3	P4.2	P4.1	P4.0
0A	0	0	0	0	1	0	1	0
88	1	0	0	0	1	0	0	0
A0	1	0	1	0	0	0	0	0
22	0	0	1	0	0	0	1	0



Types of Stepper Motor:

There are three main types of stepper motors, they are:

- 1. Permanent magnet stepper
- 2. Hybrid synchronous stepper
- 3. Variable reluctance stepper

Permanent Magnet Stepper Motor: Permanent magnet motors use a permanent magnet (PM) in the rotor and operate on the attraction or repulsion between the rotor PM and the stator electromagnets.

Variable Reluctance Stepper Motor: Variable reluctance (VR) motors have a plain iron rotor and operate based on the principle that minimum reluctance occurs with minimum gap, hence the rotor points are attracted toward the stator magnet poles.

Hybrid Synchronous Stepper Motor: Hybrid stepper motors are named because they use a combination of permanent magnet (PM) and variable reluctance (VR) techniques to achieve maximum power in a small package size.

Advantages of Stepper Motor:

- 1. The rotation angle of the motor is proportional to the input pulse.
- 2. The motor has full torque at standstill.
- 3. Precise positioning and repeatability of movement since good stepper motors have an accuracy of 3-5% of a step and this error is non-cumulative from one step to the next.
- 4. Excellent response to starting, stopping and reversing.
- 5. Very reliable since there are no contact brushes in the motor. Therefore the life of the motor is simply dependant on the life of the bearing.
- 6. The motors response to digital input pulses provides open-loop control, making the motor simpler and less costly to control.
- 7. It is possible to achieve very low speed synchronous rotation with a load that is directly coupled to the shaft.
- 8. A wide range of rotational speeds can be realized as the speed is proportional to the frequency of the input pulses.

Applications:

- 1. **Industrial Machines** Stepper motors are used in automotive gauges and machine tooling automated production equipment.
- 2. **Security** new surveillance products for the security industry.
- 3. **Medical** Stepper motors are used inside medical scanners, samplers, and also found inside digital dental photography, fluid pumps, respirators and blood analysis machinery.



4. **Consumer Electronics** – Stepper motors in cameras for automatic digital camera focus and zoom functions.

Interfacing Diagram:




Figure 8.2 Interfacing Diagram of stepper motor with C8051F340

Hardware Connections:

Connect flat cable between PL3 connector of ASK25 and PL6 connector of EPBF340 board. Connect stepper motor at PL4 connector of ASK25. Connect 9V power supply at PL9 connector of ASK25 before connecting the stepper motor. Press DIP switch SW9 on ASK25 to run the motor.

Pin	PL3 Connector	PL6 Connector of
Connection	of ASK25	EPBF340
11	Input 1 (A)	P4.1
13	Input 2 (B)	P4.3
15	Input 3 (C)	P4.5
17	Input 4 (D)	P4.7
19	5V	5.0 V
20	GROUND	GND



Program: Attach printout of the tested code.

Expected Result:
Stepper Motor will rotate in the clockwise and anticlockwise direction
Conclusion:

Study Questions:


- 1. Explain different types of stepper motors and its applications.
- 2. Explain full stepping & half stepping concept of stepper motor.
- 3. List specifications of stepper motor and explain need of diver.

Additional Links:

https://nptel.ac.in/courses/112103174/16



Interfacing of Stepper motor with C8051F340.





Code for Full Stepping in Clockwise Direction:

```
// Exp 9 Interfacing of Stepper motor with C8051F340
// Full Stepping in Clockwise Direction
Name: Shreerang Mhatre
Rollno: 52
Class: TY
#include "C8051F340.h"
void delay(unsigned int Ms);
void main()
    char a[4]=\{0x02, 0x20, 0x80, 0x08\};
    int i;
    P4MD0UT=0xFF;
    while(1)
        for(i=0; i<4;i++)
            P4=a[i];
            delay(60);
void delay(unsigned int Ms)
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)</pre>
        for(j=0;j<65;j++);
```



Code for Full Stepping in AntiClockwise Direction:

```
// Exp 9 Interfacing of Stepper motor with C8051F340
// Full Stepping in AntiClockwise Direction
Name: Shreerang Mhatre
Rollno: 52
Class: TY
#include "C8051F340.h"
void delay(unsigned int Ms);
void main()
    char a[4]=\{0x02,0x08, 0x80, 0x20\};
    int i;
    P4MD0UT=0xFF;
    while(1)
        for(i=0; i<4;i++)
            P4=a[i];
            delay(60);
void delay(unsigned int Ms)
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)</pre>
        for(j=0;j<65;j++);
```



Code for Half Stepping in Clockwise Direction:

```
// Exp 9 Interfacing of Stepper motor with C8051F340
// Half Stepping in Clockwise Direction
Name: Shreerang Mhatre
Rollno: 52
Class: TY
#include "c8051F340.h"
void delay(unsigned int Ms);
void main()
    char a[]={0x02, 0x22, 0x20, 0xA0,0x80,0x80,0x88,0x0C};
    int i;
    P4MD0UT=0xFF;
    while(1)
        for(i=0; i<8;i++)
            P4=a[i];
            delay(60);
void delay(unsigned int Ms)
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)</pre>
        for(j=0;j<65;j++);
```



Code for Half Stepping in AntiClockwise Direction:


```
// Exp 9 Interfacing of Stepper motor with C8051F340
// Half Stepping in AntiClockwise Direction
Name: Shreerang Mhatre
Rollno: 52
Class: TY
#include "c8051F340.h"
void delay(unsigned int Ms);
void main()
    char a[]={0x02, 0x0A, 0x08, 0x88,0x80,0xA0,0x20,0x22};
    int i;
    P4MD0UT=0xFF;
    while(1)
        for(i=0; i<8;i++)
            P4=a[i];
            delay(60);
void delay(unsigned int Ms)
    unsigned int n;
    unsigned int j;
    for(n=0;n<Ms;n++)</pre>
        for(j=0;j<65;j++);
```



Demonstration of Full Stepping and Half Stepping in Clockwise Direction



Demonstration of Full Stepping and Half Stepping in AntiClockwise Direction





Dr. Vishwanath Karad MIT WORLD PEACE UNIVERSITY | PUNE TECHNOLOGY BESEARCH SOCIAL INNOVATION & PARTNERSHIPS

*	Full step			ock.			00	B	
	windings	P	2	-		B		A	
	sequence in	P4.7	P4-6	P4-5	P4.4	P4.3	P4·2	P4-1	P4.0
	02	0	0	0	0	0	0		0
	08	0	0	0	0	1	0	0	0
	80	1	0	0	0	0	0	.0	0
	20	0	0	1	0	0	0	0	0
	unsigninte; pumb while for 2 3	OUT (i)	=0;		è++		(O2, C	×0 8;	0×8





						DATE	111	
A A				1 2	-	K	AB	
Full stop	pine	, Ar	pick	ockn	vice.	4	1	3
windings	D		C		B	101	A	1
geowence in nex on Port 4	P4.7	P4-6	P4.5	P4-4	P4.3	P4-2	P4.1	P4.0
102	0	0	0	0	0	0	d	0
20	10	0	91	0	0	0	0	0
80	11.	00	0	0	0	0	0	0
08	0	0	00	0	1	0	0	0
0 0 0	0	00	0	0	0	0	0	0
void ma § unsig intu p4 Mi while a for	ped DOUT	cho = 0x	FF;	rod:		×02, 5×80	0 x 2	0 0 8
	рч	= 0	[i]	`	1	-110	5	
		lay (0	= 27	VA		
3)		9		
3		1-1-1		27	D=N	9		
2	CLUZ.		1	Ja)	rolet			
Void d	elay	(on	sign	od	inh	Ms)	22	
	1						8	
1/0	ode,)					y	



Dr. Vishwanath Karad MIT WORLD PEACE UNIVERSITY | PUNE TECHNOLOGY BESEARCH SOCIAL INNOVATION & PARTNERSHIPS

							FAGE No.		
							GATE	11	7
-	2474	, ,	,	r)	1	CAA	AB	-	7
*	Half Ste	ppin	9 6 100	- k wie	e-(05	B		-
						DC D	80		1
	winding 5.	D	01.6	0	P4,4	B	MI ION	A	1
0.4	on Port 4	84.7	P4.6	P4:5		P4.3	P4.2	P4-1	P4.04
	02 0 A	0	0	0	0	0	0	1	0
_	08	0	0	10	0	1	0	0	0
-0	88	1	0	0	0		0	0	0
11 0	80	A	0	0	0	0	0	0	10
11 9	AO	1	0	511	0	0	0	0	0
	20	0	0	1	0	0	0	0	10
	22	0	0	5/1/C	0	0	0	1	0
	il	ANTE	Wi Jo	DY B	in	DVD	001	UCV.	
	code:	- ((,)	MA	197 E	100	
	# includ	0 (805	1 -34	0.h	01=).	1000	5	
1,58	Void peb	y Cl	onsi	gne	ا ال	(VIS)			
	S ma	IY)C)		1990	×O.E.	ruedi	2 20		
	unsign	ned	char	as]=30	0x02.	Ox O	A, Ox	08
	inte					0×88,			
	P4 MD	JU T=	OXF	ら	000	0x20,	0x2	23,	
	while	(1)		F + 1		100	3	-	
	3	()		Via	DE	4			
+	For	(le=	20;	2485	e++)))	5	-941	-
	1	P4=	a [i	1.			5		
		dola	y (50	3.				5	
	3	Vala	100		20)	dolay	bus	TO I	
	34							2	
-	3	- (950			_
-	void del	aylur	nsi gr	ied in	MS))			
	2 3"000	0							



						SATE	//	
Half Ste	ppin	g A	ohi c	locky	vise,	or es		
windings	D	MILE ST	TC		В		A	
seavin, hex on	P4.7	P4-6	124.5	P4.4	1943	P4.2	104.1	P4.
02	0	0	0	0	0	0	1	0
22	6	0	1	0	0	0	1	0
20	0	0	14	0	0	0	0	0
AO	1	0	1	0	0	0	0	0
86	1	0	0	0	0	0	0	0
88	1	0	0	0	1	0	0	0
08	6	0	0	0	ı	0	0	0
OC	0	0	0	0	1	0	1	0
- 1000		1		1	1			1
rode! # meloi	1 ((2))	-		
H moles	de	- C80	511-	240,V	1			
11 1000	1	110		011	1 4467			
Nord Drov	elay	(Un	Si'gn	ed in	(2M)	jane	ale s	+
void Drov	elay	(Un	Sign	ed ir	(SM)	<i>j</i>	ode 3	*
void De	in ((Un)	Sign	edir	MS)			5.7/
void ma	in ((Un)	Sign	edir	MS)	2,0	×22,0	0×20
void De	elay in C	(bn)	esign er ai	PJ =	MS)	0,0,	×22,0	0×8
void De void ma § unsign intès P4 MD	elay in C	(bn)	esign er ai	PJ =	MS)	0,0,	×22,0	0×8
void De	elay in C	(bn)	esign er ai	PJ =	MS)	0,0,	×22,0	0×8
void De	ned nout	(br) cha	sign ar ai	EJ=	0x0 0x0	0,0,	×22,0	0×8
void De void ma § unsign intej P4 MD while	ned nout	(br) cha	sign ar ai	PJ =	0x0 0x0	0,0,	×22,0	0×8
void De	ned nout	(bx) $= 0x$	sign ar ai	EJ=	0x0 0x0	0,0,	×22,0	0×8
Void De Void ma & Unsign intel Pu MI While & For	play $\frac{1}{1}$	(br) cha = 0x	Sign ar ai FF; ei{8	EJ=	0x0 0x0	0,0,	×22,0	0×8
Void De Void ma & Unsign inter pu MD While & for	ned nout	(br) cha = 0x	Sign ar ai FF; ei{8	EJ=	0x0 0x0	0,0,	×22,0	0×8
Void De Void ma & void ma	play $\frac{1}{1}$	(br) cha = 0x	Sign ar ai FF; ei{8	EJ=	0x0 0x0	0,0,	×22,0	0×8
void De void ma se unsign inter pu MD white se for	play $\frac{1}{1}$	(br) cha = 0x	Sign ar ai FF; ei{8	EJ=	0x0 0x0	0,0,	×22,0	0×8



	PLGE No.
*	Postlab Questions -
	As Explain full stepping & half shood
(31)	Explain different types of Stepper motors
	and its applications.
	- gaiggade that De
->0	Permanent Magnet Stepper Motor (PM)-
116	These motors are relatively simple
	and cost-offective but may have lower
	torque & precision compared to other types.
ort	used in applications like printors
T	plotters & low-precision positioning sys.
01	a ma-phase mater, each shap vanils
(2)	Variable Reluctance Stopper Motor (VR)-
0-1	They offer a moderate level of
	torque & precision. However, they can
	be noisy and are less common than
	other types.
asitalo	used in applications like textile machinery
	disk drivers & some CVC machines.
	elected at a particular of the paralleles
(3)	Hybrid Stepper Motor of
- aul	provide a balance between costs
chem	precision, and lorgue. They are the
cod	most common type of stopper motor
ent-	and offer good all-around performance.
	used in various applications,
	including 30 printers one machines,
	including 30 printers inc machines, mobolics & campra lons focusing systems
	148, 4, 150 (b) (b) (b) (B) B & S = 0 co.



Dr. Vishwanath Karad MIT WORLD PEACE UNIVERSITY | PUNE TECHNICIA ON DESCRAPTH SOCIAL INNOVATION & PARTMERSHIPS

(32)	Explain full stepping & half stepping concept of stepper motor.
	DFull stepping, each coil or phase of the stepper motor is energized to its foll extent one at a time. Each step in a full-stepping security results in a 90- degree rotation of the motor shaft in a four -phase motor. To a two-phase motor, each step results in a 160-degree so rotation. Full stepping provides more to repet but a coarser resolution. Half stepping provides a finer redult and smoother as the rotor can be positioned at an intermediate angle between the foll steps. To half stepping, a combination of two adjacent phases is onergized gimultarea. This results in move steps per rotation of smaller stepping se avuence would
CHEST	involve the following activations AB, A, BC, Ct, CD, D, DA, B & so on.



	FAGE NO. CATE //
0,3	List specifications of depper motor explain need of driver.
	specifications of stepper motor are - Step Angle
3	Rated Current Resistance and Inductance
6	Physical size operating voltage
	Astepper motor driver is essential for controlling the precise motion and
	It provides the recessary olectrical
	signals to the motor, enabling accurate positioning, speed control and microstepping for applications that require high
	precision and reliability. Additionally, stepper motor drivers offer protection features and interface compatibility,
	making them crucial components for integrating stepper motors.