

Comply

Resistance Factor or 'μ' value should be minimum 7000. Density of insulation shall be between 40 to 50 Kg/m³. For pipe dia. up to 3 inches, tube insulation should be used. The tubes shall be fully factory (machine) slit along each length with two strips of double sided self-adhesive tape pre-applied to each open slit surface. The self-tape adhesive shall be solvent free acrylic with high initial tack and high peel strength. For pipe dia. 4 inches & above, sheet insulation should be used.

Duct Insulation Installation

Sheet metal ducts shall be insulated as per method given below:

- i) Duct surfaces shall be cleaned to remove all grease, oil, dirt, etc. prior to carrying out insulation work.
- ii) Measurement of surface dimensions shall be taken properly to cut closed cell elastomeric rubbers sheets to size with sufficient allowance in dimension.
- iii) Material shall be fitted under compression and no stretching of material should be allowed.
- iv) A thin film of adhesive (Pidilite SR 505 / Insulation manufacturer recommended adhesive) shall be applied on the back of the insulating material sheet and then on to the metal surface.
- v) When adhesive is tack dry, insulating material sheet shall be placed in position and pressed firmly to achieve a good bond.
- vi) All longitudinal and transverse joints shall be sealed as per manufacturer recommendations.
- vii) All joints will be covered with overlapping self-adhesive tape 50 mm wide, procured from manufacture of same material as the base insulation. (All corners shall be sealed with 50 mm wide self-adhesive aluminum foil).
- viii) Fix PVC strapping 25 mm wide at 600 mm intervals.

Noted

Piping Insulation

The thickness of piping insulation for various pipe sizes operating under different temperature ranges shall be as given in bill of quantities.

Method: Application for Nitrile Rubber Insulation:

- vii) Brush and clean the pipes to ensure removal of rust, dust, grease, etc.
- viii) Apply minimum 2 coats of zinc chromate primer.
- ix) Apply thin film of adhesive (Pidilite SR 998 / Insulation manufacturer recommended adhesive) and leave it 2 – 3 min. to let it become tacky.
- x) Press the sheets in portion and butt the joints well together.
- i) Apply 75 mm self-adhesive tape of same material on both type of joints (longitudinal and transverse direction). Tape shall be min. 2.5 mm thick.

Noted

