US. NIOSH: Pocket Guide to Chemical Hazards Recommended Exposure Limits (REL)						
Components	Туре	Value Form				
PROPAN-2-OL (CAS 67-63-0)	STEL	1225 mg/m3				
		500 ppm				
	TWA	980 mg/m3				
		400 ppm				
TOLUENE (CAS 108-88-3)	STEL	560 mg/m3				
		150 ppm				
	TWA	375 mg/m3				
		100 ppm				

## **Biological limit values**

**ACGIH Biological Exposure Indices (BEI)** 

Components	Value	Determinant	Specimen	Sampling Time
BENZENE (CAS 71-43-2)	25 µg/g	S-Phenylmerca pturic acid	Creatinine in urine	*
PROPAN-2-OL (CAS 67-63-0)	40 mg/l	Acetone	Urine	*
TOLUENE (CAS 108-88-3)	0.3 mg/g	o-Cresol, with hydrolysis	Creatinine in urine	*
	0.03 mg/l	Toluene	Urine	*
	0.02 mg/l	Toluene	Blood	*

<sup>\* -</sup> For sampling details, please see the source document.

## **Exposure guidelines**

## US - California OELs: Skin designation

1-Methoxypropan-2-ol (CAS 107-98-2)

BENZENE (CAS 71-43-2)

Cun be absorbed through the skin.

CUMENE (CAS 98-82-8)

Can be absorbed through the skin.

US - Minnesota Haz Subs: Skin designation applies

CUMENE (CAS 98-82-8) Skin designation applies. TOLUENE (CAS 108-88-3) Skin designation applies.

US - Tennessee OELs: Skin designation

CUMENE (CAS 98-82-8)

Can be absorbed through the skin.

US ACGIH Threshold Limit Values: Skin designation

BENZENE (CAS 71-43-2) Danger of cutaneous absorption

US NIOSH Pocket Guide to Chemical Hazards: Skin designation

CUMENE (CAS 98-82-8)

Can be absorbed through the skin.

US. OSHA Table Z-1 Limits for Air Contaminants (29 CFR 1910.1000)

CUMENE (CAS 98-82-8)

Can be absorbed through the skin.

Appropriate engineering controls

Use adequate ventilation to control airborne concentrations below the exposure limits/guidelines. If user operations generate a vapor, dust and/or mist, use process enclosure, appropriate local exhaust ventilation, or other engineering controls to control airborne levels below the recommended exposure limits/guidelines.

Individual protection measures, such as personal protective equipment

Eye/face protection Wear safety glasses with side shields (or goggles).

Skin protection

Hand protection
Suitable chemical protective gloves should be worn when the potential exists for skin exposure.

The choice of an appropriate glove does not only depend on its material but also on other quality features and is different from one producer to the other. Use protective gloves made of: Polyvinyl

chloride (PVC). Rubber gloves.

**Other** Wear appropriate chemical resistant clothing if applicable.

**Respiratory protection**If engineering controls do not maintain airborne concentrations to a level which is adequate to protect worker health, an approved respirator must be worn. Respirator selection, use and maintenance should be in accordance with the requirements of OSHA Respiratory Protection

Standard 29 CFR 1910.134 and/or Canadian Standard CSA Z94.4.

FIR No.: 174336 SDS US Version: 02 5 / 11

Issue Date: 02-19-2025