

Check List

Order Code: TGM-62016 Software code: C422

Instruction : ทดสอบการทำงานของอินพุต Remote

| 1. Config | | | | | | | |
|---------------|-------|-------------|---------|------|------|------|------|
| Function | Input | Botton | Comment | Min | Max | Pass | Fail |
| Actual | | F2 | | 0 | 999 | | |
| Decimal Point | | DP | | 0 | 2 | | |
| Input Delay | | IP TYPE | | 0.01 | 9.99 | | |
| Multiple | | SCALE+ | | 1 | 999 | | |
| Divisor | | SCALE- | | 1 | 999 | | |
| Set Point 1 | | OP MODE (1) | | 0 | 999 | | |
| Set Point 2 | | OP MODE (2) | | 0 | 999 | | |
| | | | | | | | |

Instruction : ทดสอบการทำงานของ Input

| Input | | | | | | | | |
|----------|---------------|-------------|-----|-----|------|--------|------|------|
| Function | Input | Pulse Input | MUL | DIV | IND | Actual | Pass | Fail |
| Counter | Pulse Counter | 100 | 1 | 1 | 0.01 | 100 | / | |
| | | 100 | 1 | 2 | 0.01 | 50 | / | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |

Instruction : ทดสอบการทำงานของ Output

| Output | | | | | | | | |
|----------|-------------|-----------|-------|--|--|--------|------|------|
| Function | Output | Set Alarm | Value | | | Active | Pass | Fail |
| | | 250 | 249 | | | OFF | / | |
| | | 250 | 251 | | | ON | / | |
| | Set Point 1 | | | | | | | |
| | | | | | | | | |
| Counter | | | | | | | | |
| | | 250 | 249 | | | OFF | / | |
| | | 250 | 251 | | | ON | / | |
| | Set Point 2 | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |

| Prepared By | Verified By | Approved By |
|-------------|-------------|-------------|
| | | |