First batch of CBV001 DIY kits using the pre-populated SMD board (before 17/01/2023) got an issue in which the output level is too low. It can be fixed by soldering a 1k resistor accross R11, however since R11 is a tiny SMD resistor, it might be easier to solder the 1k resistor between VR1 pin 3 and VR4 pin 2 as shown here :

