INDEX

	Subject	Chapter	Section Pag	зе
E	EDIT Keys EDIT LOCK Switch Editing Operation, Summary of EIA/ISO Auto-Recognition	. 4	4.1.1011 6.1.2816 4.8.414 3.1.211	17 62 46 10
	EMERGENCY STOP Pushbutton	. 2	2.9.7 2	27 05
F	F1-Digit Programming †	. 2	2. 9. 32 ···· 8 6. 1. 3 ···· 19 2. 4. 5 ··· 3 2. 4. 2 ··· 1	80 55 12 10
	Feedrate 1/10	. 6	6.1.13 ····· 19 6.1.12 ···· 19 4.1.3 ···· 13 8.4.1 ···· 18	59 57 15 84
	Fuse for Servo Control Power Unit	. 8	8.3.31	83
G	G Codes and Groups, List of	. 2	2. 9. 2 · · · · · · · · · · · · · · · · · ·	23 23 24
	(G04) Dwell	. 2	2.9.8	45 . 28
	(G20, G21) [†] Inch/Metric Designation by G Code	. 2	2.9.12 2.9.13 2.9.14 2.9.15	35
	(G30) [†] Reference Point Return (G31) [†] Skip Function (G33) [†] Threadcutting (G36, G37) [†] Automatic Centering Function (G38) [†] Z-Axis Reference Surface Offset	. 2	2.9.17	36 37 37
•	(G40, G41, G42)†Tool Radius Compensation C (G43, G44, G49)†Tool Length Compensation (G45 to G48) Tool Position Offset (G50, G51)†Scaling Function (G52 to G59)†Work Coordinate System Setting	2	· 2.9.22 ····· · 2.9.23 ····· · 2.9.24 ····· · 2.9.25 ····	53 55 60 62
	(G60) [†] Unidirectional Approach (G70, G71, G72) Hole Pattern Cycles (G73, G74, G76, G80 to G89, G98, G99) [†] Canned Cycles (G80, G81) [†] Output for External Motion (G90/G91) Absolute/Incremental Programming	2	· 2.9.29 ····· · 2.9.29 ····	68 67
	(G92) Programming of Absolute Zero Point		• 2.9.32	80