

Server/PC Hardware Setup & Rocky Linux Booting Process

Tom Goncin

July 6th, 2026

ENSE 353 — Lab 1

Table of Contents

Objective (What did we do?):	3
Steps (How did we do it?)	4
Outcome (Why did we do it?)	5

Objective

(What did we do?):

Assembly of server hardware, enter & configure the BIOS for virtualization and automatic power recovery.

Install a partitioned Rocky Linux OS.

Steps

(How did we do it?)

1. Attain server/pc, mouse, keyboard, HDMI cable, power cable, USB
2. Install RAM & hard drive
3. Turn on PC
If there is an error or beeping, clarify RAM & hard drive are properly plugged in
4. Provided USB contains a bootable Rocky Road Linux community version OS
5. Plug USB into PC
Note:
Often you must plug it into the rear as even if configured to the front ports they will not be enabled.
6. Turn on PC & press F2 for BIOS
7. Once in BIOS, click AC Recovery, and set as power on to turn back in case of a power outage.
8. In BIOS, enter “USB Configuration”, and enable “USB Boot Support”
9. Again, in BIOS, enter “Virtualization” & enable “USB Boot Support”
10. For “Install Destination”, custom, delete all old configurations except USB “sda”
11. Go to “Auto Partition”, and remove “/home” and add remaining space to “/”. Then save.
12. Create root account & leave box unchecked so the root can not log in remotely.
13. Create user

Copernicus
C*****m*****
14. Begin installation, and check “Reboot System” when complete
15. If an issue arises, force restart/reboot. It may have not rebooted itself to fully load.
16. Once installed and booted, log into root

root
C*****4
17. Shut down machine. Do not shut down manually, force shutdown from terminal:

“shutdown -h now”
-h = halt
now = immediately
18. Leave PC until Wednesday.

Outcome

(Why did we do it?)

Provisioned a stable, virtualization-ready server that is capable of auto-recovering from a power outage, ensuring a full functionality & that a secure environment is ready for further development Wednesday.