

Setting Parameters for the Line-Measuring Robot

How to Set Parameters - initial_position[2]

1. Double-click *line-measurer* under MULTI-MODELS and click to expand the Configuration section:




2. Scroll down to the *Initial values of parameters* section at the bottom. This lists all the *Instances* (of FMUs in the co-simulation). Now click *Edit*.




3. Select the {body}.body instance. The Parameters section shows the available parameters for this Instance, in this case initial_position[2]. Values are:


Straight line: 0.785Curved line: 5.497Unknown line: 2.356



- 4. Click Save.
- 5. Changing the multi-model configuration affects the co-simulation configuration (called *run*) which will produce the following error: "Multimodel crc check failed. Multimodel has changed."



6. To fix this, click to expand the *Configuration*, press *Edit*, then immediately press *Save*.



How to Set Parameters - Sensor Positions

1. Repeat Steps 1–6 but select the relevant *{sensor}.sensor* instance. These are colour-coded in the 3D visualisation to match the live plot in the INTO-CPS tool.

