Assignment – Lecture 21

1. Represent the following sine waves in phasor form:
   i) v_1(t) = 200sin($100\pi t + 60^0$) Volts
   ii) v_2(t) = 300cos($100\pi t - 30^0$) Volts

   Comment on the phase relation between them & draw the phasor diagram.