

20 x 20 Data Scale P.M. List

Daily

- Check the scale for proper weight display. Use a known weight and check to ensure the scale is weighing properly. If not weighing properly then go through the calibration process.

Weekly

- On the indicator there is a rubber seal on the inside of the front half make sure the seal is inside the groove and make sure the seal is in good condition. Also make sure the screws on the corners are in good shape and are tight but do not overtighten. Check that the grommets on the bottom of the indicator are tight to the indicator and also the caps are tight to the wires. This helps maintain the best defense against moisture inside the indicator and on the control board.
- Check to make sure all wire landings are secure and that no connections have come loose or have been pulled loose.

Monthly

- Go through entire system to make sure all nuts are tight and all bolts are present.