


SOL calibration standards and where they place Γ on the Smith Chart



Standard	$ \Gamma $	Phase	Purpose
Short	1	180°	Reference plane position
Open	1	0°	Phase reference (with fringing C corr.)
50 Ω Load	0	—	Amplitude reference, sets return loss scale
Through	—	0°	2-port: transmission reference