## Урок 5. Интерфейс I2C на примере работы с датчиком влажности и температуры

Если у вас есть датчик, поддерживающий I2C, подключите его и воспользуйтесь программой из методички. Для удобства можно выводить каждый шаг программы через Serial.print(). Так будет больше понимания работы библиотеки Wire.h. Если вы являетесь обладателем нескольких датчиков, подключите их и обратитесь к каждому по адресу.

Подключим датчик жестов (приближения и освещённости) APDS9930 по шине I2C.

Программа меняет яркость свечения светодиода через ШИМ и выводит значение расстояния через Serial.print().

```
#define DUMP_REGS
#define PWM LED PIN
                         10
#include <Wire.h>
#include <APDS9930.h>
// Global Variables
APDS9930 apds = APDS9930();
uint16 t proximity data = 0;
int proximity max = 0;
void setup() {
//analogReference(EXTERNAL);
 pinMode(PWM LED PIN, OUTPUT);
// Initialize Serial port
 Serial.begin(9600);
Serial.println();
 Serial.println(F("-----"));
 Serial.println(F("APDS-9930 - ProximityLED"));
Serial.println(F("----"));
```

```
// Initialize APDS-9930 (configure I2C and initial values)
 if ( apds.init() ) {
  Serial.println(F("APDS-9930 initialization complete"));
} else {
  Serial.println(F("Something went wrong during APDS-9930 init!"));
}
// Adjust the Proximity sensor gain
 if (!apds.setProximityGain(PGAIN 1X)) {
  Serial.println(F("Something went wrong trying to set PGAIN"));
}
// Start running the APDS-9930 proximity sensor (no interrupts)
 if ( apds.enableProximitySensor(false) ) {
  Serial.println(F("Proximity sensor is now running"));
} else {
  Serial.println(F("Something went wrong during sensor init!"));
}
#ifdef DUMP_REGS
/* Register dump */
uint8 t reg;
 uint8_t val;
for(reg = 0x00; reg <= 0x19; reg++) {
  if( (reg != 0x10) && \
    (reg != 0x11))
  {
   apds.wireReadDataByte(reg, val);
   Serial.print(reg, HEX);
```

```
Serial.print(": 0x");
   Serial.println(val, HEX);
  }
 }
 apds.wireReadDataByte(0x1E, val);
 Serial.print(0x1E, HEX);
 Serial.print(": 0x");
 Serial.println(val, HEX);
#endif
}
void loop() {
 // Read the proximity value
 if ( !apds.readProximity(proximity_data) ) {
  Serial.println("Error reading proximity value");
 } else {
  Serial.print("Proximity: ");
  Serial.print(proximity_data);
  Serial.print(F(" Remapped: "));
  Serial.println(proximity data);
  analogWrite(PWM_LED_PIN, proximity_data);
 }
// Wait 250 ms before next reading
 delay(10);
}
Результат работы программы показан на видео: APDS9930.mp4
```