How to upload firmware to control board from PC

Operation system: Windows 32 bit or 64 bit system

Tools: USB cable

Software: Arduloader 1.0

- Step 1. Install USB to UART bridge chip driver (CP2012).
- Step 2. Download Arduloader 1.0 from cloud disk and store it to PC.
- Step 3. Download firmware HEX file from cloud disk and store it to PC.
- Step 4. Connect the control board to PC by USB cable.
- Step 5. Copy the HEX file with Arduloader 1.0 to the same directory.
- Step 6. Execute Arduloader 1.0, choose HEX file which need to be uploaded, set com port and select the board type, click upload button to go!!.

Arduloader 1.0 download link: https://www.jianguoyun.com/p/DXDxIRIQyoP1BxiaggID

HEX file download link: https://www.jianguoyun.com/p/Dd00chMQyoP1BxiCo8IC

CP2102 driver download link: https://www.jianguoyun.com/p/DRBp2j8QyoP1BxijqqID

NOTE 1: Save the Arduloader to a simply directory in your PC

NOTE 2: We suggest to turn off AC power when upload firmware.

NOTE 3: If there are fails many times in uploading, please try to replug the USB cable or replace a

new USB cable and try again.

Install USB to UART bridge chip driver (CP2012)

1. Execute this file: \CP2102\windows\CP210x_Windows_Drivers\CP210xVCPInstaller_x64.exe

Note: You may need to unzip the compressed file before installation.




2. Connect the printer to the PC with a USB cable.





Download Arduloader 1.0 and HEX file

Download Arduloader 1.0



Unzip it



Download HEX file




Store the HEX file to the same Directory

| \mu avrtool | 2020/3/11 17:00 | 文件夹 | |
|-----------------------------|------------------|------------------|-----------|
| 🛂 Arduloader user guide.pdf | 2019/10/25 11:48 | PDF Document | 307 KB |
| Arduloader.exe | 2017/3/29 19:22 | 应用程序 | 11,107 KB |
| boards.txt | 2020/3/4 18:52 | Text Document | 2 KB |
| config.ini | 2020/3/30 15:46 | Configuration Se | 1 KB |
| Z9F_TT_LCD12864_V21_en.hex | 2020/6/12 20:29 | HEX 文件 | 426 KB |
| | | | |
| | | | |

Execute Arduloader




Tools GUI



Upload frimware

Plug USB to PC, you can see the com port




Click browse and choose HEX file



Set comport and control board



Click Upload bottom to start



Wait until it shows "SUCEESS"

| D:/3dp/Arduload | ler/Z9F_TT_LCD12 | 864_V21_en. hex | ₩ Browser |
|-----------------|---------------------------------------|-----------------|----------------------|
| COM3 💠 | ZRIB w/Arduino | Mega 2560 16mhz | (for P802 Z8 Z9 Z10) |
| Start uploading | 5 | | |
| | | | |
| | | | |
| | | | |
| | · · · · · · · · · · · · · · · · · · · | | |
| Upload SUCCESS: | | | |
| | | | |

DONE!