

MANUFACTURING PLAN

RAW MATERIAL STOCK:

STEP	PROCESS DESCRIPTION	MACHINE	FIXTURE	TOOL(S)	SPEED (RPM)
1	Cut down to 1.25" in bandsaw	bandsaw			300 ft/sec
2	place in vise	Mill	Vise with 1.375" parallels		
3	Cut down to 1.00"	Mill	Cutting tool	Cutting Tool	700
4	Centerdrill	Mill	Vise with 1.375" parallels		100
5	Drill .375" hole thru	Mill	Vise with 1.375" parallels	Drill bith with drill chuck	700
6	Filp part	Mill	Vise with 1.375" parallels	-	-
7	Cut off top of part with passes	Mill	Vise with 1.375" parallels	Cutting tool with chuck	700
8	Cut Counterbore with .137" cutting bit with .0625" depth	Mill	Vise with 1.375" parallels	Cutting bit with chuck	700
9	Cut hole thru with .075" cutting bit	Mill	Vise with 1.375" parallels	cutting but with chuck	700
10	Deburr	file	-	file	

В

A

В

SHEET 2 OF 2