Mechatronics 3DX4

Slides 8: Root Locus Techniques

Dr. O. Onaizah

Department of Computing and Software McMaster University

Material based on Control Systems Engineering by N. Nise.

Introduction

- ► The root locus technique shows graphically how the closed-loop poles change as a system parameter is varied.
- Used to analyze and design systems for stability and transient response.
- Shows graphically the effect of varying the gain on things like percent overshoot, and settling time.
- Also shows graphically how stable a system is; shows ranges of stability, instability, and when system will start oscillating.

The Control System Problem

- ▶ The poles of the open-loop transfer function are typically easy to find and do not depend on the gain, *K*.
- It is thus easy to determine stability and transient response for an open-loop system.

$$\blacktriangleright \ \, \mathrm{Let} \,\, G(s) = \frac{N_G(s)}{D_G(s)} \,\, \mathrm{and} \,\, H(s) = \frac{N_H(s)}{D_H(s)}.$$




Figure 8.1.

The Control System Problem - II

Our closed transfer function is thus

$$T(s) = \frac{K\frac{N_G(s)}{D_G(s)}}{1 + K\frac{N_G(s)}{D_G(s)}\frac{N_H(s)}{D_H(s)}}$$
(1)

$$= \frac{KN_G(s)D_H(s)}{D_G(s)D_H(s) + KN_G(s)N_H(s)}$$
(2)

We thus see that we have to factor the denominator of T(s) to find the closed-loop poles, and they will be a function of K.




Figure 8.1(b).

The Control System Problem - III

▶ For example, if $G(s) = \frac{s+1}{s(s+2)}$ and $H(s) = \frac{s+3}{s+4}$, our closed-loop transfer function is:

$$T(s) = \frac{K(s+1)(s+4)}{s(s+2)(s+4) + K(s+1)(s+3)}$$
(3)

$$=\frac{K(s+1)(s+4)}{s^3+(6+K)s^2+(8+4K)s+3K}$$
(4)

- ➤ To find the poles, we would have to factor the polynomial for a specific value of K.
- ► The root-locus will give us a picture of how the poles will vary with K.

Vector Representation of Complex Numbers

- ▶ Any complex number, $\sigma + j\omega$, can be represented as a vector.
- ▶ It can be represented in polar form with magnitude M, and an angle θ , as $M \angle \theta$.
- If F(s) is a complex function, setting $s=\sigma+j\omega$ produces a complex number. For F(s)=(s+a), we would get $(\sigma+a)+j\omega$.




Figure 8.2.

Vector Representation of Complex Numbers - II

- ▶ If we note that function F(s) = (s+a) has a zero at s=-a, we can alternately represent $F(\sigma+j\omega)$ as originating at s=-a, and terminating at $\sigma+j\omega$.
- ▶ To multiply and divide the polar form complex numbers, $z_1 = M_1 \angle \theta_1$ and $z_2 = M_2 \angle \theta_2$, we get

$$z_{1}z_{2} = M_{1}M_{2}\angle(\theta_{1} + \theta_{2}) \qquad \frac{z_{1}}{z_{2}} = \frac{M_{1}}{M_{2}}\angle(\theta_{1} - \theta_{2}) \qquad (5)$$

$$\downarrow s\text{-plane} \qquad \downarrow \rho \qquad \downarrow \rho$$

Figure 8.2.

Polar Form and Transfer Functions

For a transfer function, we have:

$$G(s) = \frac{(s+z_1)\cdots(s+z_m)}{(s+p_1)\cdots(s+p_n)} = \frac{\prod_{i=1}^m (s+z_i)}{\prod_{i=1}^n (s+p_i)} = M_G \angle \theta_G$$
(6)

where

$$M_G = \frac{\prod_{i=1}^{m} |(s+z_i)|}{\prod_{i=1}^{n} |(s+p_i)|} = \frac{\prod_{i=1}^{m} M_{z_i}}{\prod_{i=1}^{n} M_{p_i}}$$
(7)

and

$$\theta_G = \Sigma zero \ angles - \Sigma pole \ angles$$
 (8)

$$= \sum_{i=1}^{m} \angle(s+z_i) - \sum_{j=1}^{n} \angle(s+p_j)$$
 (9)

Polar Form and Transfer Functions eg.

▶ Use Equation 6 to evaluate $F(s) = \frac{(s+1)}{s(s+2)}$ at s = -3 + j4.




Figure 8.3.

Polar Form and Transfer Functions eg.




Figure 8.3.

Check answer using matlab:

```
1    s=tf('s')
2    F= (s+1)/(s*(s+2))
3    s1=evalfr(F,-3+j*4)
4    M=abs(s1)
5    theta=angle(s1)
6    theta*180/pi
©2006-2012,2017 R.J. Leduc & M. Lawford
```

Root Locus Introduction

- System below can automatically track subject wearing infrared sensors.
- ➤ Solving for the poles using the quadratic equation, we can create the table below for different values of K.

Table 8.1.

K	Pole 1	Pole 2		
0	-10	0		
5	-9.47	-0.53		
10	-8.87	-1.13		
15	-8.16	-1.84		
20	-7.24	-2.76		
25	-5 5 + 224	-5 5 224		
30 35	-5 + j2.24 -5 + j3.16	-5 - j2.24 -5 - j3.16		
40	-5 + j3.16 -5 + j3.87	-5 - j3.16 -5 - j3.87		
45	-5 + j3.67 -5 + j4.47	-5 - j4.47		
50	-5 + i5	-5 - i5		






Figure: 8.4

Root Locus Introduction - II

▶ We can plot the poles from Table 8.1. labelled by their corresponding gain.

Table 8.1.

K	Pole 1	Pole 2		
0	-10	0		
5	-9.47	-0.53		
10	-8.87	-1.13		
15	-8.16	-1.84		
20	-7.24	-2.76		
25	-5	-5		
30	-5 + i2.24	-5 - i2.24		
35	-5 + i3.16	-5 - i3.16		
40	-5 + i3.87	-5 - j3.87		
45	-5 + i4.47	-5 - j4.47		
50	-5 + i5	-5 - i5		




Figure: 8.5

Root Locus Introduction - III

- We can go a step further, and replace the individual poles with their paths.
- We refer to this graphical representation of the path of the poles as we vary the gain, as the root locus.
- ▶ We will focus our discussion on $K \ge 0$.
- ▶ For pole $\sigma_D + j\omega_D$, $T_s = \frac{4}{\sigma_D}$, $T_p = \frac{\pi}{\omega_D}$, and $\zeta = \frac{|\sigma_D|}{\omega_n}$.




Figure 8.5.

Root Locus Properties

- ► For second-order systems, we can easily factor a system and draw the root locus.
- ► We do not want to have to factor for higher-order systems (5th, 10th etc.) for multiple values of *K*!
- We will develop properties of the root locus that will allow us to rapidly sketch the root locus of higher-order systems.
- Consider the closed-loop transfer function below:

$$T(s) = \frac{KG(s)}{1 + KG(s)H(s)}$$

ightharpoonup A pole of T(s) exists when

$$KG(s)H(s) = -1 = 1\angle(2k+1)180^{o}$$
 $k = 0, \pm 1, \pm 2, \dots$ (10)

Root Locus Properties - II

► Equation 10 is equivalent to

$$|KG(s)H(s)| = 1 \tag{11}$$

and


$$\angle KG(s)H(s) = (2k+1)180^{o}$$
 (12)

- ▶ Equation 12 says that any s' that makes the angle of KG(s)H(s) be an odd multiple of 180^o is a pole for some value of K.
- ▶ Given s' above, the value of K that s' is a pole of T(s) for is found from Equation 11 as follows:

$$K = \frac{1}{|G(s)||H(s)|} \tag{13}$$

Root Locus Properties eg.


For system below, consider s=-2+j3 and $s=-2+j(\sqrt{2}/2)$.



Figures 8.6 and 8.7.

Sketching Root Locus

- Now give a set of rules so that we can quickly sketch a root locus, and then we can calculate exactly just those points of particular interest.
 - 1. Number of branches: a branch is the path a single pole traverses. The number of branches thus equals the number of poles.
 - **2. Symmetry:** As complex poles occur in conjugate pairs, a root locus must be symmetric about the real axis.



Sketching Root Locus - II

3. Real-axis segments: For K > 0, the root locus only exists on the real axis to the left of an odd number of finite open-loop poles and/or zeros, that are also on the real axis.

Why? By Equation 12, the angles must add up to an odd multiple of 180.

- A complex conjugate pair of open-loop zeros or poles will contribute zero to this angle.
- An open-loop pole or zero on the real axis, but to the left of the respective point, contributes zero to the angle.
- ► The number must be odd, so they add to an odd multiple of 180, not an even one.




Figure 8.8.

Sketching Root Locus - III

4. Starting and ending points: The root locus begins at the finite and infinite poles of G(s)H(s) and ends at the finite and infinite zeros of G(s)H(s).

Why? Consider the transfer function below

$$T(s) = \frac{KN_G(s)D_H(s)}{D_G(s)D_H(s) + KN_G(s)N_H(s)}$$

► The root locus begins at zero gain, thus for small K, our denominator is

$$D_G(s)D_H(s) + \epsilon \tag{14}$$

▶ The root locus ends as K approaches infinity, thus our denominator becomes

$$\epsilon + KN_G(s)N_H(s)$$

Infinite Poles and Zeros

Consider the open-loop transfer function below

$$KG(s)H(s) = \frac{K}{s(s+1)(s+2)}$$
 (15)

- From *point 4*, we would expect our three poles to terminate at three zeros, but there are no finite zeros.
- A function can have an infinite zero if the function approaches zero as s approaches infinity. ie. $G(s) = \frac{1}{s}$.
- A function can have an infinite pole if the function approaches infinity as s approaches infinity. ie. G(s) = s.
- When we include infinite poles and zeros, every function has an equal number of poles and zeros

$$\lim_{s \to \infty} KG(s)H(s) = \lim_{s \to \infty} \frac{K}{s(s+1)(s+2)} \approx \frac{K}{s \cdot s \cdot s}$$
 (16)

How do we locate where these zeros at infinity are so we can terminate our root locus?

Sketching Root Locus - IV

5. Behavior at Infinity: As the locus approaches infinity, it approaches straight lines as asymptotes.

The asymptotes intersect the real-axis at σ_a , and depart at angles θ_a , as follows:

$$\sigma_a = \frac{\Sigma \text{finite poles} - \Sigma \text{finite zeros}}{\# \text{finite poles} - \# \text{finite zeros}}$$
(17)

$$\theta_a = \frac{(2k+1)\pi}{\# \text{finite poles} - \# \text{finite zeros}} \tag{18}$$

where $k=0,\pm 1,\pm 2,\pm 3$, and the angle is in radians relative to the positive real axis.

Sketching Root Locus eg. 1

▶ Sketch the root locus for system below.




Figure 8.11.

Real-axis Breakaway and Break-in Points

- Consider root locus below.
- ▶ We want to be able to calculate at what points on the real axis does the locus leave the real-axis (breakaway point), and at what point we return to the real-axis (break-in point).
- At breakaway/break-in points, the branches form an angle of $180^o/n$ with the real axis where n is number of poles converging on the point.




Figure 8.13.

Real-axis Breakaway and Break-in Points - II

- Breakaway points occur at maximums in the gain for that part of the real-axis.
- Break-in points occur at minimums in the gain for that part of the real-axis.
- We can thus determine the breakaway and break-in points by setting $s=\sigma$, and setting the derivative of equation below equal to zero:




Figure 8.13.

Real-axis Breakaway and Break-in Points - III

An alternative method for computing the real-axis breakaway and break-in points without differentiation is to solve the equation:

$$\sum_{i=1}^{m} \frac{1}{\sigma + z_i} = \sum_{i=1}^{n} \frac{1}{\sigma + p_i}$$
 (8.37)

where z_i and p_i are the negative of the zeros and poles, respectively, of G(s)H(s). i.e.

$$G(s)H(s) = \frac{K_{GH}(s+z_1)(s+z_2)\dots(s+z_m)}{(s+p_1)(s+p_2)\dots(s+p_n)}$$

The $j\omega$ -Axis Crossings

- For systems like the one below, finding the $j\omega$ -axis crossing is important as it is the value of the gain where the system goes from stable to unstable.
- Can use the Routh-Hurwitz criteria to find crossing:
 - 1. Force a row of zeros to get gain
 - Determine polynomial for row above to get ω, the frequency of oscillation.





Figure 8.12.

The $j\omega$ -Axis Crossing eg.

▶ For system below, find the frequency and gain for which the system crosses the $j\omega$ -axis.



Figures 8.11 and 8.12.

Angles of Departure and Arrival

- We can refine our sketch by determining at which angles we depart from complex poles, and arrive at complex zeros.
- Net angle from all open-loop poles and zeros to a point on root access must satisfy:

$$\Sigma$$
zero angles – Σ pole angles = $(2k+1)180^o$ (20)

▶ To find angle θ_1 , we choose a point ϵ on root locus near complex pole, and assume all angles except θ_1 are to the complex pole instead of ϵ . Can then use Equation 20 to solve for θ_1 .




Figure 8.15.

Angles of Departure and Arrival - II

For example in Figure 8.15a, we can solve for θ_1 in equation below:

$$\theta_2 + \theta_3 + \theta_6 - (\theta_1 + \theta_4 + \theta_5) = (2k+1)180^o$$
 (21)

- Similar approach can be used to find angle of arrival of complex zero in figure below.
- ▶ Simply solve for θ_2 in Equation 21.





Figure 8.15.

Angles of Departure and Arrival eg.


► Find angle of departure for complex poles, and sketch root locus.



Figures 8.16 and 8.17.

Plotting and Calibrating Root Locus

- Once sketched, we may wish to accurately locate certain points and their associated gain.
- ► For example, we may wish to determine the exact point the locus crosses the 0.45 damping ratio line in figure below.
- From Figure 4.17, we see that $\cos(\theta) = \frac{\text{adj}}{\text{hyp}} = \frac{\zeta \omega_n}{\omega_n} = \zeta$.
- ▶ We then use computer program to try sample radiuses, calculate the value of s at that point, and then test if point satisfies angle requirement.




Plotting and Calibrating Root Locus - II

▶ Once we have found our point we can use the equation below to solve for the required gain, *K*.

$$K = \frac{1}{|G(s)||H(s)|} = \frac{\prod_{i=1}^{m} M_{p_i}}{\prod_{i=1}^{n} M_{z_i}}$$
(22)

▶ Uses labels in Figure 8.18, we would have for our example:

$$K = \frac{ACDE}{B} \tag{23}$$



Figures 4.17 and 8.18.

Transient Response Design via Gain Adjustment

- ▶ We want to be able to apply our transient response parameters and equations for second-order underdamped systems to our root locuses.
- ► These are only accurate for second-order systems with no finite zeros, or systems that can be approximated by them.
- What are the conditions that must be true for a 2nd order approximation to be "close" to the higher order system?


Recall if
$$G(s)=\frac{N_G(s)}{D_G(s)}$$
 and $H(s)=\frac{N_H(s)}{D_H(s)}$, closed loop TF is:

$$T(s) = \frac{KN_G(s)D_H(s)}{D_G(s)D_H(s) + KN_G(s)N_H(s)}$$
(24)

Transient Response Design via Gain Adjustment II

Conditions for justifying 2^{nd} order approx of a higher order systems

- 1. Higher order poles are much farther left (e.g. $> 5 \times$) of the s-plane dominant closed loop poles. (Holds for (b), not (a))
- 2. The closed-loop zeros near the two dominant closed-loop poles must be nearly canceled by higher-order poles near them. (Holds for (d), not (c))
- **3.** Closed-loop zeros not cancelled, must be far away from the two dominant closed-loop poles.



Defining Parameters on Root Locus

- We have already seen that as $\zeta = \cos \theta$, vectors from the origin are lines of constant damping ratio.
- As percent overshoot is solely a function of ζ , these lines are also lines of constant %OS.
- From diagram we can see that the real part of a pole is $\sigma_d = \zeta \omega_n$, and the imaginary part is $\omega_d = \omega_n \sqrt{1 \zeta^2}$.
- As $T_s=rac{4}{\zeta\omega_n}=rac{4}{\sigma_d}$, vertical lines have constant values of T_s .




Figure 4.17.

Defining Parameters on Root Locus - II

- As $T_p=\frac{\pi}{\omega_n\sqrt{1-\zeta^2}}=\frac{\pi}{\omega_d}$, horizontal lines thus have constant peak time.
- ▶ We thus choose a line with the desired property, and test to find where it intersects our root locus.





Figure 4.17.

Design Procedure For Higher-order Systems

- 1. Sketch root locus for system.
- 2. Assume system has no zeros and is second-order. Find gain that gives desired transient response.
- **3.** Check that systems satisfies criteria to justify our approximation.
- **4.** Simulate system to make sure transient response is acceptable.


Third-order System Gain Design eg.

- ▶ For system below, design the value of gain, *K*, that will give 1.52% overshoot. Also estimate the settling time, peak time, and steady-state error.
- First step is to sketch the root locus below.
- We next assume system can be approximated by second-order system, and solve for ζ using $\zeta = \frac{-\ln(\%OS/100)}{\sqrt{\pi^2 + \ln^2(\%OS/100)}}$.



Third-order System Gain Design eg. - II

- This gives $\zeta = 0.8$. Our angle is thus $\theta = \cos^{-1}(0.8) = 36.87^{o}$.
- ► We then use root locus to search values along this line to see if they satisfy the angle requirement.
- The program finds three conjugate pairs on the locus and our $\zeta=0.8$ line. They are $-0.87\pm j0.66,\ -1.19\pm j0.90,\ -4.6\pm j3.45$ with respective gains of K=7.36,12.79, and 39.64.
- $lackbox{We will use } T_p = rac{\pi}{\omega_d}, \ {\rm and} \ T_s = rac{4}{\sigma_d}.$



Third-order System Gain Design eg. - III

For steady-state error, we have:

$$K_v = \lim_{s \to 0} sG(s) = \lim_{s \to 0} s \frac{K(s+1.5)}{s(s+1)(s+10)} = \frac{K(1.5)}{(1)(10)}$$
 (25)

- ➤ To test to see if our approximation of a second-order system is valid, we calculate the location of the third pole for each value of K we found.
- ▶ The table below shows the results of our calculations.

Case	Closed-loop poles	Closed-loop zero	Gain	Third closed-loop pole	Settling time	Peak time	Κ _ν
1	$-0.87 \pm i0.66$	-1.5 + i0	7.36	-9.25	4.60	4.76	1.1
2	$-1.19 \pm j0.90$	-1.5 + j0	12.79	-8.61	3.36	3.49	1.9
3	$-4.60 \pm j3.45$	-1.5 + j0	39.64	-1.80	0.87	0.91	5.9

Table 8.4.

Third-order System Gain Design eg. - IV

▶ We now simulate to see how good our result is:




Figure 8.23.