


PLUTO Runtime Software Flowchart

A safety-supervised state machine: boot validation, idle supervision, operating modes, and recovery



Connectors: A = normal exit back to IDLE

E = enter ERROR safe lock

All motion states pass through STM32 safety supervision before any motor command reaches the hoverboard.

Color key: ■ Boot ■ Idle ■ Manual ■ Dance ■ Welcome ■ Error