



WORK INSTRUCTIONS

ReDry 2-Way Vent — Cap the Bases

For Abby & Alberto · August 2026 · Batch of about 100 bases

THE JOB

A batch of about 100 aluminum bases gets the **white temporary cap** only — no vent body, sleeve, or hood. Cap each base, then pack them eight to a box.

The cap is **not** used when assembling full vents — that is a [separate job](#).

CAP EACH BASE

1 Press the cap onto the standpipe

Push the white temporary cap down onto the standpipe until it seats.



2 Drive the cap screw

Drive the screw through the cap into the standpipe so the cap cannot pull off.

BOX THEM — 8 PER BOX

3 First layer: four upright in the divider

Set the cardboard cross divider in the box. Stand **four capped bases upright** — flange down, cap up — one in each section.

4 Second layer: four on their sides

Lay **four more bases sideways on top**: each flange against a box wall, capped standpipe pointing to the center. Turn each one 90° from the last so they nest into a pinwheel.

Close the flaps and seal like any box: gummed tape in an H pattern, ReDry-printed tape strip on top.

FINAL CHECK BEFORE IT LEAVES YOUR STATION

- ☐ Cap seated and screwed on every base
 - ☐ Four upright in the divider, four nested sideways on top
 - ☐ Nothing shifts when the box is closed
 - ☐ Box sealed: H pattern + ReDry tape
-