





# UART -> USB Debug Port

UART debug messages available via a USB port and a 3 pin jumper for TX, RX, and GND UART connections



Sheet: /USB\_debug\_APM/  
File: USB\_debug\_APM.kicad\_sch

**Title:**


Size: A4

Date:

KiCad E.D.A. 10.0.4

Rev:

Id: 2/6



Sheet: /USB\_MIDI\_APM/  
File: USB\_MIDI\_APM.kicad\_sch

**Title:**

Size: A4

Date:


KiCad E.D.A. 10.0.4

**Rev:**

Id: 3/6

# Power Monitor and Supply

PMS has an INA219 current sensor  
for each board/node in the  
PCB. Each takes in the 5V from it's  
parent board and supplies 5V to said  
board's circuit (its peripherals)  
thus enabling monitoring



Sheet: /PMS\_APM/  
File: PMS\_APM.kicad\_sch


**Title:**

Size: A4  
KiCad E.D.A. 10.0.4

Date:

**Rev:**

Id: 4/6



Sheet: /THERMISTORS\_APM/  
File: THERMISTORS\_APM.kicad\_sch

**Title:**


Size: A4

Date:

KiCad E.D.A. 10.0.4

**Rev:**

Id: 5/6



Sheet: /STORAGE\_APM/  
File: STORAGE\_APM.kicad\_sch

**Title:**

Size: A4

Date:

Rev:

KiCad E.D.A. 10.0.4

Id: 6/6