

MoveMode	Action on Receipt
Stop	If moving, stop, else ignore the command (i.e., the command is accepted but has no effect). This SHALL stop any ongoing hue and/or saturation transition.
Up	Increase the device's saturation at the rate given in the Rate field. If the saturation reaches the maximum allowed for the device, stop.
Down	Decrease the device's saturation at the rate given in the Rate field. If the saturation reaches the minimum allowed for the device, stop.

3.2.8.9. StepSaturation Command

This command will change the device to the requested saturation value using a step transition.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StepMode	StepModeEnum	all			M
1	StepSize	uint8	all			M
2	TransitionTime	uint8	all			M
3	OptionsMask	OptionsBitmap	desc			M
4	OptionsOverride	OptionsBitmap	desc			M

3.2.8.9.1. StepMode Field

This field SHALL indicate the mode of the step to be performed, as described in the [StepHue](#) command.

3.2.8.9.2. StepSize Field

This field SHALL indicate the change to be added to (or subtracted from) the current value of the device's saturation.

3.2.8.9.3. TransitionTime Field

This field SHALL indicate, in 1/10ths of a second, the time that SHALL be taken to perform the step. A step is a change in the device's saturation of Step size units.

NOTE

Here the TransitionTime data field is of data type uint8, where uint16 is more common for TransitionTime data fields in other clusters / commands.