

otes

RTC_PWR_KWY — NEEDS TO BE CONNECTED TO THE GPIO OF A MCU UART_RX1 & UART_TX1 TO BE USED FOR PROGRAMMING THE IC UART_RX2 & UART_TX2 TO BE USED TO TALK TO THE IC

