EEPROM clear tool - wiring

nothing is wired: only the USB cable between the PC and the Mega



How to use

1. Unplug everything from the Mega except the USB cable (the sign hardware may stay connected: the tool does not use any pin).
2. Upload eeprom_clear/sketch.ino. At start-up it sets every EEPROM byte to 0xFF, once.
3. Serial Monitor at 115200 baud: 'EEPROM cleared: all bytes are 0xFF.' and one DBG line per second. LED on pin 13 blinks slowly.
4. A fast blink and 'EEPROM clear FAILED' mean that some byte could not be cleared (a worn-out EEPROM).
5. Upload the sign program again: it finds no saved settings and starts with the default values of the menu.

USB cable GND