PROGRAM

1000 MOV AH,[1100]

1004 SUB AX,[1102]

1008 JNC 100B

100B INC CX

100D MOV [1200],AX

100F MOV [1202],CX

1013 HLT

OUTPUT

INPUT OUTPUT

[1100]=9999 [1200]=01

[1102]=369C [1202]=62FD