Construction Chemicals

Product Datasheet
Edition: 01 | Date: Nov 2026
Waterproofing

O-Seal PVC

PVC Waterproofing Membrane
1.5 / 2 / 3 mm



Product Description

O-Seal PVC is a flexible PVC waterproofing membrane available in 1.5, 2 and 3 mm. It resists tearing, roots and chemicals, contains no VOC, and is installed with hot-air welded seams. Two-colour layers make damage easy to detect.

Uses

- Water tanks and reservoirs.
- Channels and tunnels.
- Foundations and basements.
- Industrial ponds.
- Roof gardens and green roofs.

Advantages

- Root and tear resistant.
- Chemical resistant.
- Hot-air welded seams.
- Two-colour signal layer for inspection.
- Elongation ≥ 300 %.

Application

1. **Surface Preparation**
   Concrete ≥ 25 MPa, smooth, clean; install protection geotextile (Geomat).
2. **Laying**
   Unroll the membrane with 5 – 10 cm overlaps.
3. **Welding**
   Weld overlaps with hot air; use double-track welds in critical areas and test seams.

Consumption

approx. 1.1 m² per m²
including 5 – 10 cm overlaps
Add details and upstands as per drawings.

Packaging

Rolls 2.2 m × 20 m; thickness 1.5, 2 or 3 mm.

Storage & Shelf Life

Store rolls horizontally in a dry, shaded place, away from heat and sharp objects.

Technical Data

Typical values at 25 °C

Property	Typical Value	Test Method
Material	Flexible PVC	—
Thickness	1.5 / 2 / 3 mm	—
Tensile strength	≥ 15 – 16 N/mm²	—
Elongation	≥ 300 %	—
Tear resistance	≥ 400 – 500 N	—
Fire class	E (B1)	—
Cold flexibility	-20 °C to -30 °C	—
VOC	Free	—
Roll size	2.2 m × 20 m	—

Consumption

Item	Requirement
Overlap	5 – 10 cm
Critical areas	Double-track weld with air channel
Substrate	Concrete ≥ 25 MPa, smooth

Consumption is theoretical and varies with substrate porosity, profile and application method.

Application Conditions

- Substrate smooth, clean and free of sharp edges.
- Concrete compressive strength ≥ 25 MPa.
- Weld only clean, dry overlaps.
- Do not weld in rain.

Application Notes

- Use Geomat geotextile as a protection layer under and over the membrane where specified.
- Weld trial seams each day to set temperature and speed.
- Test seams by probing; test double-track seams by air pressure.
- Protect the finished membrane before backfilling or screeding.

Health & Safety

- Hot-air welders reach high temperatures; avoid burns.
- Avoid inhaling fumes from overheated PVC.
- Use cut-resistant gloves when cutting.

First Aid & Cleaning

- Burns: cool with water and seek medical advice.
- Inhalation of fumes: move to fresh air.
- Cuts: clean and dress the wound.
- Clean welding nozzles with a wire brush.

The information in this datasheet is based on laboratory tests and practical experience and is given in good faith. Users should verify product suitability for their specific application. O MIX reserves the right to update this information without prior notice.