

I - Wiring Harnesses: Parts




I - Assembly of Carbon Fiber Tube

1 - Solder three wires to each temperature sensor, insert one into carbon fiber sleeve bracket with carbon fiber tube and a fourth. separate stripped wire. Use Epoxy

2 - crimp and connect the three soldered wires to a Male 3 POS wire housing



I - Assembly of Carbon Fiber Tube (cont)




4 - Insert the other end of the carbon fiber tube into the other bracket with the additional wire from Step 3. Use Epoxy, once again, to hold everything in place.



5 - insert plastic tube into carbon fiber tube

I - Assembly of Needle Mount




he placed. 2 - Solder three wires to each temperature sensor, insert one

I - Assembly of Needle Mount (cont)

4 - Crimp and connect the separate wire, and one additional wire, to a Male 2 POS housing connector


5 - crimp and connect the three soldered wires to a Male 3 POS wire housing connector



I - Additional Steps

1 - Solder three wires to each temperature sensor

3 - Crimp and connect three separate wires to a female 2 POS housing connector



housing connector