Nuclear Fuel Performance

NE-533

Spring 2023

Exam Notes

- Avg 89.5, no curve implemented
- Pretty good all around
- If you have questions or comments, please reach out to me


Last Time

- Temporal and spatial discretization for numerical integration
- Forward and Backward Euler (Explicit and Implicit methods)
 - explicit can be sensitive to the timestep size
 - implicit are harder to implement, but more stable for stiff problems
- Finite difference, volume, and element
 - all three are used in fuel performance codes and have strengths/weaknesses
 - FD is fast, but works on a grid and is discrete
 - FE is most flexible, continuous, utilized in MOOSE
- Started into mechanics with concept of elasticity

MECHANICS


Elasticity

- Elasticity is the ability of a body to resist a distorting influence and to return to its original size and shape when that influence or force is removed
- In elastic deformation, we are stretching the atomic bonds
- The more we stretch the bonds, the more force it takes to stretch
- When we release the load, the atoms spring back into their lattice sites




Plasticity

- Plasticity is the ability of a solid material to undergo permanent deformation, a non-reversible change of shape in response to applied forces
- Plastic deformation is observed in most materials
- The transition from elastic behavior to plastic behavior is known as yielding




Plasticity

- Plasticity is typically caused by two modes of deformation in the crystal lattice: slip and twinning
 - Slip is a shear deformation which moves the atoms through many interatomic distances relative to their initial positions
 - Twinning is the plastic deformation which takes place along two planes due to a set of applied
- Ductility (total elongation), Yield Strength, etc. are dependent upon temperature and composition
- Plasticity typically increases at higher temperature



Stress


- Stress is a physical quantity that expresses the internal forces that neighboring particles of a continuous material exert on each other
- Stress is a force per unit area with SI units of Pa = N/m²
- The stress is a 2nd order tensor (a 3 by 3 matrix): Cauchy stress tensor
- $\bullet \quad \sigma_{ij} = F_{ij}/A_i$
 - i is the face the force is applied and j is the direction it is applied
- Sigmas are normal stress components, taus are shear stress components




$$\boldsymbol{\sigma} = \begin{bmatrix} \sigma_{11} & \sigma_{12} & \sigma_{13} \\ \sigma_{21} & \sigma_{22} & \sigma_{23} \\ \sigma_{31} & \sigma_{32} & \sigma_{33} \end{bmatrix} \equiv \begin{bmatrix} \sigma_{xx} & \sigma_{xy} & \sigma_{xz} \\ \sigma_{yx} & \sigma_{yy} & \sigma_{yz} \\ \sigma_{zx} & \sigma_{zy} & \sigma_{zz} \end{bmatrix} \equiv \begin{bmatrix} \sigma_{x} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_{y} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_{z} \end{bmatrix}$$


Stress as a response

- The stress in a material is the RESPONSE to an applied load (force) or an applied displacement
- Uniaxial tension or compression
 - Only one non-zero stress: σ_{ii} (σ_{11} , σ_{22} , σ_{33})
 - Tension means positive stress, compression negative
 - Examples: Cables, tension tests
- Pure shear
 - Only one non-zero stress: $(\sigma_{12}, \sigma_{13}, \sigma_{23})$
 - Examples: drive shaft
- Biaxial tension/compression
 - Two non-zero stress (e.g. $\sigma_{11} = 1$, $\sigma_{22} = 2$)
 - Examples: Pressure cylinder or vessel
- Hydrostatic compression (pressure)
 - $\sigma_{11} = \sigma_{22} = \sigma_{33} = -p$
 - Anything underwater









Strain

- Strain is a geometrical measure of deformation representing the relative displacement between particles in a material body
- The strain in a tensile test is the deformation divided by a representative length


$$e = \frac{\Delta L}{L} = \frac{\ell - L}{L}$$

- This is engineering strain, but strain can also be defined as "true strain," accounts for shrinking of section area and the effect of developed elongation on further elongation
- Strain is a second order tensor, like the stress
 - Let u be a vector of the displacements
 - The small strain tensor is

$$\epsilon_{ij} \equiv \frac{1}{2} \left(\frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right)$$

For, like the stress displacements
$$\begin{bmatrix} \epsilon_{11} & \epsilon_{12} & \epsilon_{13} \\ \epsilon_{21} & \epsilon_{22} & \epsilon_{23} \\ \epsilon_{31} & \epsilon_{32} & \epsilon_{33} \end{bmatrix} = \begin{bmatrix} \frac{\partial u_1}{\partial x_1} & \frac{1}{2}(\frac{\partial u_1}{\partial x_2} + \frac{\partial u_2}{\partial x_1}) & \frac{1}{2}(\frac{\partial u_1}{\partial x_3} + \frac{\partial u_3}{\partial x_1}) \\ \frac{1}{2}(\frac{\partial u_2}{\partial x_1} + \frac{\partial u_1}{\partial x_2}) & \frac{\partial u_2}{\partial x_2} & \frac{1}{2}(\frac{\partial u_2}{\partial x_3} + \frac{\partial u_3}{\partial x_2}) \\ \frac{1}{2}(\frac{\partial u_3}{\partial x_1} + \frac{\partial u_1}{\partial x_3}) & \frac{1}{2}(\frac{\partial u_3}{\partial x_2} + \frac{\partial u_2}{\partial x_3}) & \frac{\partial u_3}{\partial x_3} \end{bmatrix}$$

• The common strain states are the same as the stress (uniaxial tension, etc.)



Strain produces stress


- A deformation (strain) results in stress within a material
- $\sigma = F(\epsilon)$
- For small strains, the stress is elastic and is a linear function of the strain

$$oldsymbol{\sigma} = \mathcal{C}(oldsymbol{\epsilon})$$

 For larger deformation, some of the strain is elastic and increases the stress. The rest is plastic and does NOT contribute to the stress.


$$oldsymbol{\epsilon} = oldsymbol{\epsilon}_e + oldsymbol{\epsilon}_p \ oldsymbol{\sigma} = oldsymbol{\mathcal{C}} oldsymbol{\epsilon}_e$$


• The elastic energy density in a material is a scalar quantity equal to $E_{el} = \frac{1}{2} \epsilon_e \cdot \sigma$



Tensile testing

- The most common means of determining mechanical properties is a uniaxial tension test
- Apply a uniaxial load until failure
- Properties that are directly measured via a tensile test include ultimate tensile strength, maximum elongation, etc., which can be utilized to determine Young's modulus, Poisson's ratio, etc.







Stress/strain from a tensile test


- A_{θ} = Initial cross section area
- A =deformed cross section area
- P or F applied load/force

	Engineering	True
stress σ	$\frac{F}{A_0}$	$\frac{F}{A}$
strain ε	$rac{l-l_o}{l_o}$	$\int_{l_o}^{l} \frac{dl}{l} = ln \left(\frac{l}{l_o} \right)$



Stress vs strain curves






Using stress/strain curves


- In the elastic portion of the stress-strain curve, the stress varies linearly with strain
- The slope of the line is Young's Modulus, E: $\sigma = E \ \epsilon$
- Poisson's ratio, v, is the ratio of the shrinkage in cross section due to the extension in the pulling direction

 $\nu = -\frac{d\varepsilon_{\rm trans}}{d\varepsilon_{\rm axial}} = -\frac{d\varepsilon_{\rm y}}{d\varepsilon_{\rm x}} = -\frac{d\varepsilon_{\rm z}}{d\varepsilon_{\rm x}} \qquad \qquad \nu \approx \frac{\Delta L'}{\Delta L}.$

 Can obtain the shear modulus from the elastic modulus and Poisson's ratio

 $G=\frac{E}{2(1+\nu)}$






Using stress/strain curves

• The shear modulus, *G*, defines the stress to strain ratio in shear

$$\sigma_{12} = G\epsilon_{12}$$

- For isotropic materials, G = E / (2(1 + v))
- In matrix form, the elasticity/stiffness tensor from Hooke's law for isotropic materials can be written as

$$\begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ 2\varepsilon_{23} \\ 2\varepsilon_{13} \\ 2\varepsilon_{12} \end{bmatrix} = \begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ \gamma_{23} \\ \gamma_{13} \\ \gamma_{12} \end{bmatrix} = \begin{bmatrix} 1 & -\nu & -\nu & 0 & 0 & 0 \\ -\nu & 1 & -\nu & 0 & 0 & 0 \\ -\nu & -\nu & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 2 + 2\nu & 0 & 0 \\ 0 & 0 & 0 & 0 & 2 + 2\nu & 0 \\ 0 & 0 & 0 & 0 & 0 & 2 + 2\nu \end{bmatrix} \begin{bmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{23} \\ \sigma_{13} \\ \sigma_{12} \end{bmatrix}$$




$$arepsilon_{ij} = rac{1}{E}ig(\sigma_{ij} -
u(\sigma_{kk}\delta_{ij} - \sigma_{ij})ig) \ \delta_{ij} = egin{cases} 0 & ext{if } i
eq j, \ 1 & ext{if } i = j. \end{cases}$$

Isotropic and Anisotropic

- Being a linear mapping between the nine numbers σ_{ij} and the nine numbers ε_{kl} , the stiffness tensor **c** is represented by a matrix of $3 \times 3 \times 3 \times 3 = 81$ real numbers
- Given minor symmetries of the stiffness tensor, $c_{ijkl} = c_{jikl}$, this 81 elastic constants can be reduced to 36
- Major symmetries, $c_{ijkl} = c_{klij}$, reduce this number from 36 to 21
- Isotropic materials deform the same way no matter in what direction you deform them.
 - They have 2 unique elastic constants, C₁₁ and C₁₂
- Anisotropic materials behave differently in different directions
 - The elasticity tensor can have 21 unique components defining anisotropy
 - Orthotropic materials have 9 unique elastic constants
 - Cubic structured materials have 3 unique elastic constants (UO₂)
 - Hexagonal structured materials have 5 unique elastic constants
- Polycrystalline anisotropic materials can behave as isotropic, because the various grains average out

$$oldsymbol{arepsilon} oldsymbol{arepsilon} = egin{bmatrix} arepsilon_{11} & arepsilon_{12} & arepsilon_{13} \ arepsilon_{21} & arepsilon_{22} & arepsilon_{23} \ arepsilon_{31} & arepsilon_{32} & arepsilon_{33} \end{bmatrix}; \hspace{0.5cm} oldsymbol{\sigma} = egin{bmatrix} \sigma_{11} & \sigma_{12} & \sigma_{13} \ \sigma_{21} & \sigma_{22} & \sigma_{23} \ \sigma_{31} & \sigma_{32} & \sigma_{33} \end{bmatrix} \ \sigma_{ij} = - \sum_{l=1}^{3} \sum_{l=1}^{3} c_{ijkl} arepsilon_{kl} \end{aligned}$$






Isotropic elastic constants for some materials


Material	E (GPa)	ν
Aluminum	70.3	0.345
Gold	78.0	0.44
Iron	211.4	0.293
Nickel	199.5	0.312
Tungsten	411.0	0.28
Zircaloy	80.0	0.41
UO ₂	200.0	0.345


Elastic constants are not "constant"

- Properties change with temperature
- Softening can be referred to as the decrease in elastic constants with temperature
- Young's modulus is typically a function of temperature, decreasing with increasing temperature
- Shear Modulus and Poisson's ratio can also change with T



In actual materials, the stress and the strain change throughout the material






von Mises yield criterion


- The maximum distortion criterion (also von Mises yield criterion) states that yielding of a ductile material begins when the second invariant of deviatoric stress (J2) reaches a critical value
- A material is said to start yielding when the von Mises stress reaches the yield strength
- The von Mises stress satisfies the property where two stress states with equal distortion energy have an equal von Mises stress
- The von Mises stress is used to predict yielding of materials under complex loading from the results of uniaxial tensile tests

$$\sigma_{
m v}^2 = rac{1}{2} \left[(\sigma_{11} - \sigma_{22})^2 + (\sigma_{22} - \sigma_{33})^2 + (\sigma_{33} - \sigma_{11})^2 + 6 \left(\sigma_{23}^2 + \sigma_{31}^2 + \sigma_{12}^2
ight)
ight]$$




Stress/Strain Regions

- Once the stress reaches the yield stress, it plastically deforms
- σ_{y} is the yield stress
- σ_U is the ultimate tensile stress
- The final stress before rupture is called the fracture stress



Permanent Strain

- After plastic deformation, if you unload the sample, it still has the permanent strain
- The plastic behavior has modified the microstructure, and has increases the yield point
- After unloading, the strain hardening has changed the material
- Thus, if you reload, the yield strain is often higher than it was previously




The hardening behavior changes for different materials


$$\sigma = \sigma_y + K(\epsilon_0 + \epsilon_p)^n$$

- K is a strength coefficient, n is the strain hardening exponent, ϵ_0 is the prior plastic strain, ϵ_p is the plastic strain, and σ_v is the yield strength
- The strain hardening exponent is a material property, with a value between 0 and 1
- A value of 0 means that a material is a perfectly plastic solid, while a value of 1 represents a 100% elastic solid.

• An increase in oy due to plastic deformation.




Curve fit to the stress-strain response:



Dislocation motion

- Plastic deformation occurs due to dislocation motion
- A dislocation is a line defect
 - Edge and screw type
- When it moves, only a small number of bonds are broken at a time



Adapted from Fig. 7.1, *Callister 6e.* (Fig. 7.1 is adapted from A.G. Guy, *Essentials of Materials Science*, McGraw-Hill Book Company, New York, 1976. p. 153.)



Plastically stretched zinc single crystal.

Adapted from Fig. 7.9, Callister 6e. (Fig. 7.9 is from C.F. Elam, The Distortion of Metal Crystals, Oxford University Press, London, 1935.)



Adapted from Fig. 7.8, *Callister 6e.*

Dislocation are produced during deformation





Dislocation motion causes plastic deformation, dislocation pileup causes hardening



Dislocation Pile Up


 Dislocation motion can be inhibited by barriers, including grain boundaries, precipitates, voids, bubbles, etc.





Ductility

- Ductile materials plastically deform significantly, brittle materials do not
- Quantities defining ductility are total percent elongation at fracture (%EL) and the percent reduction in area (%RA)
- The ductile—brittle transition temperature (DBTT) of a metal is the temperature at which the fracture energy passes below a predetermined value
- Below the DBTT, failure is brittle
- Cold working and neutron irradiation can increase the DBTT, potentially reducing ductility of reactor components




$$\%EL = \frac{\left(l_f - l_0\right)}{l_0} \times 100$$

$$\%RA = \frac{\left(A_0 - A_f\right)}{A_0} \times 100$$

 l_f = length at fracture A_f = section area at fracture

As the strength increases due to dislocation pile-up, the ductility decreases

- Toughness is the ability of a material to absorb energy and plastically deform without fracturing
- Toughness is related to the area under the stress-strain curve
- In order to be tough, a material must be both strong and ductile
- Materials are often work hardened prior to utilization to modify mechanical properties



Summary

- Solid mechanics predicts the deformation of a body from its applied load
- The strain defines the deformation
- The stress defines the material's response to the strain
- Materials can have recoverable and permanent deformation
 - Elastic deformation is recoverable and occurs due to the stretching of the atomic lattice
 - Plastic deformation is permanent and results form the breaking of bonds
- Elastic moduli and Elastic constants