



6. Design via Root Locus

Design of cascade compensators using root locus
PI/Lag Compensator
PD/Lead Compensator
PID/Lag-Lead Compensator
Implementation of Controllers
Notch Filter

A	Improving Transient Response	ALABAMA			
	One method used to improve the transient response is P control/compensation. It is also called compensation .	D			
	The result of adding differentiation is the addition of a zero forward-path transfer function.	ero to the			
	Typically, the objective is to design a response that has a desirable overshoot and a shorter settling time than the uncompensated system.				
	One major problem with PD compensation is that PD compensation is the position of the position the position	ntrol			
	Note: The transient response of a system can be selected choosing an appropriate closed-loop pole location (design the s-plane. If this point is on the root locus , then all required is a simple gain adjustment. If the pole is not root locus , then are added to new open loop function whose root locus goes through the point.	n point) on I that is on the o produce a			

A


Ideal Derivative Compensation (PD)



☐ In PD control, ______ is added to the forward path such that the transfer function of the compensator becomes

$$G_c(s) = s + z_c$$


Example: Ideal derivative compensation speeds up the response of a system.



UncompensatedThe University of Alabama, ME 475

2


Zero at -2



Ideal Derivative Compensation (PD)



 \Box The time response of the four cases:



- ☐ All compensated cases have dominant poles with the ______, so the overshoots are almost the same.
- □ Dominant closed-loop poles with the more negative real parts have the shorter settling times.

The University of Alabama, ME 475


5



Example: PD Compensation (1/7)



☐ Given the system, design an ideal derivative compensator to yield a 16% overshoot, with a threefold reduction in settling time.



- 1. Transients
 - 1) Plot the root locus of the uncompensated system $M_p = 0.16 \implies \zeta = 0.504$
 - 2) Assume 2nd order response


$$t_s = \frac{4}{\zeta \omega_n} =$$



Example: PD Compensation (2/7)



Assumptions is justified because at K = 43.35, the third pole is at 7.59 (6 times farther from the $j\omega$ axis than the dominant poles). This can be found by Matlab or getting the closed loop TF and plugging in K, then finding the roots of the denominator.



The University of Alabama, ME 475

7



Example: PD Compensation (3/7)



- 2. Calculate the value of the design point (or desired pole).
 - This is the point that we want our new root locus to go through.
 - The real part of the pole can be found from the settling time given in the problem statement.

$$t_s = 1.107 \implies \sigma =$$

In general, $\sigma \pm j\omega_d$ is the pole. Since we know σ and we know the angle θ from the $\zeta = 0.504$ line,

$$\tan \theta = \frac{\sigma}{\omega_d} \implies \omega_d = \underline{\hspace{1cm}}$$


- So the NEW desired pole is ______
- 3. Calculate the value of K_P/K_D , the zero in the $K_D\left(s + \frac{K_P}{K_D}\right)$.
 - We want to add a zero to our system to force the Root Locus through this NEW design point.



Example: PD Compensation (4/7)



To get the actual value of the zero or (K_P/K_D) we use the fact that for the root locus to go through a point, the angle criterion must be satisfied.



The zero when added to -275.61° must give some odd multiple of $\pm 180^{\circ}$

$$\angle Zeros - 275.61^{\circ} =$$
 $\angle Zeros =$

The University of Alabama, ME 475

(




Example: PD Compensation (5/7)

THE UNIVERSITY OF ALABAMA

 $\tan(180^{\circ} - 95.6^{\circ}) = -$

To find the exact value of the zero, use the small right triangle formed between the zero, the pole, and the **real part (s)** of desired point.



X = Closed-loop pole


X =Open-loop pole




Example: PD Compensation (6/7)



- 4. Assuming a second-order system behavior, get transient quantities ζ , rise time, settling time, and the location of the third pole.
 - For uncompensated system: the second-order approximation is accurate since the third pole is at least five times the real part of the dominant, second-order pair.
 - For compensated system: the second-order approximation may be invalid because the CL third pole is at -2.775 → Simulation required!
- 5. Simulation the system meets the basic requirements!



G(s) includes plant and controller



The University of Alabama, ME 475

11



Example: PD Compensation (7/7)



	Uncompensated	Simulation	Compensated	Simulation
Plant and	K		<u>K(s+3.006)</u>	
compensator	<i>s</i> (<i>s</i> +4)(<i>s</i> +6)		s(s+4)(s+6)	
Dominant poles	$-1.205 \pm j 2.064$		$-3.613 \pm j 6.193$	
K	43.35		47.45	
ζ	0.504		0.504	
ω_n	2.39		7.17	
% overshoot	16	14.8	16	11.8
t_s	3.320	3.6	1.107	1.2
t_p	1.522	1.7	0.507	0.5
K_{v}	1.806		5.94	
$e(\infty)$	0.554		0.168	
Third pole	-7.591		-2.775	
Zero	None		-3.006	
Comments	2 nd order approx OK		Pole-zero not canceling	



Lead Compensation



☐ A passive lead compensator approximates an active ideal derivative compensator (PD controller).

$$G_c(s) =$$
______, where

- □ Advantages: (1) Passive network → no additional power supplies required. (2) noise due to differentiation is reduced.
- ☐ Disadvantage: the additional pole does not reduce the number of branches of the root locus that cross the imaginary axis into the RHP.
- ☐ To design a lead compensator, select either a compensator pole or zero arbitrarily (selection of zero first is recommended). Then use the angle criterion to find the remaining zero or pole.
- ☐ There exist more than one possible solution. The differences are in the values of static error constants, the gain required to reach the design point, the difficulty in justifying a second-order approximation and the transient response.

The University of Alabama, ME 475


13



Example: Lead Compensation (1/6)

THE UNIVERSITY OF ALABAMA

☐ Given the system, design three lead compensators that will reduce the settling time by a factor of 2 while maintaining 30% overshoot.




- 1. Transient response
 - 1) Plot the root locus of the uncompensated system

$$M_p = 0.30$$

2) Assume 2nd order response

$$t_s =$$



 $\zeta = 0.358$

The University of Alabama, ME 475

14



Example: Lead Compensation (2/6)



- 2. Find the design point
 - For a two fold reduction in settling time:

$$t_s = \frac{3.972}{2} = 1.986 \implies \sigma = \frac{4}{t_s} = \frac{4}{1.986} = 2.014$$

The imaginary part:

The imaginary part:
$$\theta = \sin^{-1}(.358) = 20.98^{\circ} \implies \tan \theta = \frac{\sigma}{\omega_d} = \frac{1}{\omega_d}$$

$$\Rightarrow \omega_d = \frac{1}{\omega_d} = \frac{1}{\omega_d}$$

The design point:

$$s = \sigma + j\omega_d =$$

- Arbitrarily choose the value of the zero 3.
 - Arbitrarily choose: $z_c = -5$


The University of Alabama, ME 475

15

Example: Lead Compensation (3/6)

ALABAMA

Use Angle criterion to calculate the pole



$$\psi_c - \theta_1 - \theta_2 - \theta_3 - \theta_c = (2k+1)180^\circ$$

$$\psi_c = \tan^{-1} \left(\frac{5.253}{5 - 2.014}\right) = 60.38^\circ$$

$$\theta_1 = \tan^{-1} \left(\frac{5.253}{4 - 2.014} \right) = 69.29^{\circ}$$

$$\theta_2 = \tan^{-1} \left(\frac{5.253}{6 - 2.014} \right) = 52.81^{\circ}$$

$$\theta_3 = 110.98^{\circ}$$

$$(2k+1)180^{\circ} = \underline{\qquad} \Rightarrow \theta_c = \underline{\qquad}$$

$$\tan(7.31^\circ) =$$
 $\Rightarrow p_c =$ $G_c(s) =$

Lead compensator


The University of Alabama, ME 475



Example: Lead Compensation (4/6)



5. Sketch the new root locus



6. Calculate the gain K

$$K = \frac{1}{|G(s_o)|}$$
, where s_o is the design point.

- 7. Verify the second-order approximation
 - Higher order poles are much farther to the left of the dominant poles.
 - Closed loop poles and zeros cancel, so second order approximation is valid.

The University of Alabama, ME 475

17



Example: Lead Compensation (5/6)



	Uncompensated	Compensation a	Compensation b	Compensation c
Plant and	K	K(s+5)	K(s+4)	<u>K(s+2)</u>
compensator	s(s+4)(s+6)	s(s+4)(s+6)(s+42.96)	s(s+4)(s+6)(s+20.09)	<i>s</i> (<i>s</i> +4)(<i>s</i> +6)(<i>s</i> +8.971)
Dominant poles	$-1.007 \pm j2.627$	$-2.014 \pm j5.252$	$-2.014 \pm j5.252$	$-2.014 \pm j5.252$
K	63.21	1423	698.1	345.6
ζ	0.358	0.358	0.358	0.358
ω_n	2.813	5.625	5.625	5.625
% overshoot	30 (28)	30 (30.7)	30 (28.2)	30 (14.5)
t_s	3.972 (4)	1.986 (2)	1.986 (2)	1.986 (1.7)
t_p	1.196 (1.3)	0.598 (0.6)	0.598 (0.6)	0.598 (0.7)
K_{v}	2.634	6.90	5.791	3.21
$e(\infty)$	0.380	0.145	0.173	0.3112
Third pole	-7.986	-43.8, -5.134	-22.06	-13.3, -1.642
Zero	None	-5	None	-2
Comments	2 nd order approx OK	2 nd order approx OK	2 nd order approx OK	No pole-zero cancellation

The University of Alabama, ME 475


18



Example: Lead Compensation (6/6)



- 8. Notice differences in the following:
 - 1) The position of the arbitrarily selected zero
 - 2) The amount of required gain, *K*.
 - 3) The position of the third and fourth poles and their relative effect upon the second-order approximation.





Lead Compensation – Less Analytical Method



- 1. Place the zero in the vicinity of the closed loop natural frequency (ω_n) . This is determined by settling time or rise time requirements.
- 2. Place the pole at a distance between 5 (_______) the value of the zero location.
- 3. Then use steps 5, 6 and 7 for the analytical method.
- 4. Note: this method will NOT force the root locus to go through a specific point, but it can place the dominant poles in a general region where the response is acceptable.
- 5. Use trial and error to improve results if necessary