LABORATORY REPORT

To: Dr.Randy Hoover

From: Benjamin LeBrun, Benjamin Garcia

Subject: Lab Assignment 7: TC2 and Servo Control

Date: April 23, 2019

Introduction

For this lab, we utilized second internal timer to the Atmega328p to produce a PWM signal to drive our robot car's servo. This required activating Timer 2 on control pin 3 and correctly setting it to output a 50 Hz control signal. This will be used to move the ultrasonic sensor 90 degrees left and right of our robot to effectively maneuvere around obsticles and walls.

Equipment

The primary devices we used were:

- Acrylic vehicle body with screws, assembled
- Elegoo Uno (chip: Atmega328p)
- HC-SR04 ultrasonic distance sensor
- SG 90 hobby servo motor
- 2 ICR18650 batteries with battery box
- Ribbon cables
- Host laptop with AVR-gcc 8-bit toolchain
- USB 2.0 A to B cable

Configuration

Our robot vehicle was assembled according to Elegoo's instructions which can be found on Elegoo's website at https://www.elegoo.com/download/. For this lab, we are using the V3.0 version of the robot kit.

While the timers and configuration are similar to the configuration and driving of the DC motors using PWM modes from the Arduino's built in timers, for our servo we require a different operating frequency than our DC motor needs. In our case, we needed to generate a 50 Hz PWM signal from the second Timer, which required using Phase corrected mode instead of the DC motor's fast PWM mode and then writing a correct pulse width to the count registers.

This allows us to call a single function with the degree angle between 0 and 180 degrees with 0 being the leftmost position.




Figure 1: Servo with ultrasonic sensor assembly.

Implementation

For this lab we are writing our own servo controller that should simply convert and assign the correct pwm mode for an approximate direction.

initServo

Initializes timer 2 and sets the phase to the correct 50 Hz signal. Also sets any pins needed by the servo.

moveServo

Takes in a degree angle, maps to a PWM value then assigns to the PWM pin controlling the servo.

mapAngle

Takes in an angle and returns a mapped PWM value for the angle, exposed to allow us to read and debug.

Discussion

With this easier lab, we did some refactoring in our code to make it a little more portable and create fewer external dependancies between our different component files from previous labs. Involved a lot of using global headers and learning how the compiler attempts to link object files together containing shared global variables.

The next issue was with range mapping and how we wrote to the timers. Finding min and max ranges was largely just creating three defines, two constants and a calculation of those that found degree steps between those ranges. This was then inserted into the code where needed to streamline the process of finding the best minimum and maximum values to calculate into the timer control register.

Responses

- 1. Not all hobby servos are made equal. Yours may have different lower/upper bounds than 1ms or 2ms. What is your servo's pulse-width response range? How many discrete steps does this translate to in your code?
 - Our range responds from approximately half a millisecond to approximately 2.3 milliseconds in pulse-width. This gives us approximately 14 steps between it's furthest left to right position with some wobble and innacuracy.
- 2. The Arduino libraries allow for any PWM pin to drive servos precisely, not just timer/counter 1. How does the Arduino source code manage this feat? You will have to do some digging and exposition here.
 - In the internal analogWrite() function inside the arduino libraries, the analog function only works on pins connected to a timer. Otherwise the arduino will switch to a digital in/out write.

Otherwise, for each induvidual pin, the internal code attempts to read the correct pin/timer combo with a switch statement and will then configure quickly the correct PWM mode that takes in a value between 0 and 255 that can be directly written to the corresponding OCRXN register. To save time and create simplicity, in processing this correct pin/timer combo, if the values are 0 or 255, the analogWrite function defaults to just writing to those pins digitally high or low.

Appendices

Table of contents:

- main.c entry, initialization and drive instructions
- bit_macros.h bit manipulations macros
- globals.h global variables needed by libraries using timers
- pcint.h Pin change interrupt header for ultrasonic sensor
- pcint.c Pin change interrupt code for ultrasonic sensor
- pin_map.h Pin map header for device
- robotio.h UART control header
- robotio.c UART control code
- servo.h Servo control library
- servo.c Servo control code
- timers.h Timers control library
- timers.c Timers control code
- ultrasonic.h Ultrasonic header file
- ultrasonic.c Ultrasonic code file

Appendix A: main.c

```
#define F_CPU 16000000
#define F.CPU 16000000

#include "bit_macros.h"

#include "pcint.h"

#include "robotlo.h"

#include "servo.h"

#include "ultrasonic.h"

#include <avr/io.h>

#include <avr/io.h>
\#include < util/delay.h>
void\ print Angle Distance (unsigned\ char\ angle\ ,\ unsigned\ int\ distance\ );
static FILE mystdout = FDEV_SETUP_STREAM(uart_putchar, NULL, _FDEV_SETUP_WRITE);
void Init()
      // configure UART and I/O initUART();
      // initialize pin change interrupts
      initPCINT();
      // configure ultrasonic range sensor initUltrasonic();
      // configure servo
      initServo();
      // Enable global interrupts
int main()
      while (1)
            fprintf(&mystdout, "Starting tests:\r\n");
// start centered
moveServo(90);
            printAngleDistance(90, readUltrasonic());
_delay_ms(500);
            // full CCW (left)
            // full CW (lett)
moveServo(180);
printAngleDistance(180, readUltrasonic());
.delay.ms(500);
// full CW (right)
moveServo(0);
printAngleDistance(0, readUltrasonic());
.delay.ms(500).
            _delay_ms(500);
for (unsigned char i = 0; i \le 180; i += 15)
                  moveServo(i);
printAngleDistance(i, readUltrasonic());
_delay_ms(500);
             _delay_ms(500);
      return 1;
}
void printAngleDistance(unsigned char angle, unsigned int distance)
       fprintf(&mystdout, "Position: %d degrees | Distance: %d cm\r\n", angle,
                  distance);
```

Appendix B: bit_macros.h

```
#ifndef _BIT_MACROS_H_
#define _BIT_MACROS_H

#define bitVal(bit) (1 << bit)
#define setBit(byte, bit) ((byte) |=(bitVal(bit)))
#define clearBit(byte, bit) ((byte) &= ^(bitVal(bit)))
#define togBit(byte, bit) ((byte) ^= (bitVal(bit)))
#endif</pre>
```

Appendix C: globals.h

Appendix F: pcint.h

```
#include "pcint.h"

/* stdout stream */
// static FILE mystdout = FDEV.SETUP.STREAM(uart.putchar, NULL,
// FDEV.SETUP.WRITE);

void initPCINT()
{
    PCMSK1 |= PCMSK1.CONFIG;
    PCICR |= PCICR.CONFIG;
}

// specific pin change interrupt handler that is less general, but
// should be faster so less time is spent in the interrupt and
// measurements are more accurate.
//
// Expects only PCINT12 active (the ultrasonic sensor input)
ISR(PCINT1.vect)
{
    // used to detect whether pcint is going high->low or low->high
    // a value of false indicates we are low->high, a value of true indicates
// high->low.
static bool highEdge = false;

if (highEdge)
{
    turnoffTimer1();
    responseAvailable = true;
}
else
{
    TIM16.WriteTCNT1(0);
    turnonTimer1();
    responseAvailable = false;
}
highEdge = !highEdge;
}
```

Appendix G: pcint.c

```
#include "pcint.h"

/* stdout stream */
// static FILE mystdout = FDEV.SETUP.STREAM(uart.putchar, NULL,
// FDEV.SETUP.WRITE);

void initPCINT()
{
    PCMSK1 |= PCMSK1.CONFIG;
    PCICR |= PCICR.CONFIG;
}

// specific pin change interrupt handler that is less general, but
// should be faster so less time is spent in the interrupt and
// measurements are more accurate.
//
// Expects only PCINT12 active (the ultrasonic sensor input)
ISR(PCINT1.vect)
{
    // used to detect whether pcint is going high->low or low->high
    // a value of false indicates we are low->high, a value of true indicates
// high->low.
    static bool highEdge = false;
    if (highEdge)
    {
        turnoffTimer1();
        responseAvailable = true;
    }
    else
    {
        TIM16.WriteTCNT1(0);
        turnonTimer1();
        responseAvailable = false;
}
    highEdge = !highEdge;
}
```

Appendix G: pin_map.h

```
#ifndef PIN_DEFS_H
#define PIN_DEFS_H
#define US.TRIG A5
#define H_A_EN 5
#define H_B_EN 6
#define H_IN1 7
#define H_IN2 8
#define H_IN3 9
#define H_IN4 11
#define IR_RECV 12
#define LED 13
#define LINE_R 10
#define LINE_M 4
 #define LINE_L 2
//<<< These are bit offsets for each pin, usable for PIN, DDR, PORT. >>> #define US.RECV 4 // PORTB #define US.ECHO 4 // PORTC #define US.TRIG 5 // PORTC
// H bridge pins
#define H.A.EN
#define H.B.EN
#define H.IN1
                              5 // PORID PMM pin
6 // PORID PMM pin
7 // PORID
0 // PORIB
1 // PORIB
3 // PORIB
#define H_IN2
#define H_IN3
#define H_IN4
#define IR_RECV 6 // PORTB
#define LED
                                 5 // PORTB
#define LINE_R 2 // PORTB
#define LINE_M 4 // PORTD
#define LINE_L 2 // PORTD
```

#endif

Appendix H: robotio.h

Appendix H: robotio.c

Appendix H: servo.h

```
#ifndef _SERVO_H_
#define _SERVO_H_
#include "bit_macros.h"
#include "rin_map.h"
#include "timers.h"
#include "timers.h"
#include <avr/io.h>

#define DEG_MAP_MAX 18
#define DEG_MAP_MIN 4
#define DEG_PER_UNIT (180 / (DEG_MAP_MAX - DEG_MAP_MIN))

void initServo();
void moveServo(unsigned char deg);
unsigned char mapAngle(unsigned char angleDeg);
#endif
```

Appendix H: servo.c

```
#include "servo.h"
/* stdout stream */
static FILE mystdout = FDEV_SETUP_STREAM(uart_putchar, NULL, _FDEV_SETUP_WRITE);
void initServo()
     // set pin and timers
// set to 1 as output
setBit(DDRD, 3);
     // init TC2
     initTimer2();
}
void moveServo(unsigned char deg) { OCR2B = mapAngle(deg); }
// mapping assumes 0 degrees is full CW (right) and 180 degrees is full CCW // (left) unsigned char mapAngle(unsigned char angleDeg) ^{\rm r}
     unsigned char result;
if (angleDeg <= 0)</pre>
          result = DEG_MAP_MIN;
     else if (angleDeg >= 180) {
          result = DEG_MAP_MAX;
     else
{
          result = DEG_MAP_MIN + (angleDeg / DEG_PER_UNIT);
     }
     fprintf(\&mystdout, \ "result \ map: \ \%d\r\n", \ result);
     return result;
```

Appendix H: timers.h

```
#ifndef _TIMERS_H_
#define _TIMERS_H_
#include "globals.h"
#include <avr/interrupt.h>
#include <avr/io.h>
#include <stdbool.h>
#include <stdbool.h>

woid turnoffTimer1();
void turnonTimer1();
void initTimer0();
void initTimer1();
void initTimer2();
void TIM16_WriteTCNT1(unsigned int i);
unsigned int TIM16_ReadTCNT1();
bool getOverflowStatus();
#endif
```

Appendix H: timers.c

```
#include "timers.h"
// Getter for overflow status
bool getOverflowStatus() { return TimerOverflow; }
// Overflow vector ISR(TIMER1_OVF_vect)
      // Timer 1 overflow
TimerOverflow = true;
void initTimer0()
      // set both motors to start off OCR0A = 0; OCR0B = 0;
      // start TCNT0 at 0
      TCNT0 = 0x00;
      // Enable fast pwm mode for DC motor output
     // Enable fast pwm mode for LC mor
TCCR0A = 0xA3;
TCCR0B = 0x05; // 1024 prescaler
// TCCR0B = 0x04; // 256 prescaler
// TCCR0B = 0x03; // 64 prescaler
// TCCR0B = 0x02; // 8 prescaler
// TCCR0B = 0x01; // 1 prescaler
      // Enable counter match interrupt for counter A
      TIMSK0 = 0x02;
void initTimer1()
       * Timer 1
* Pins 7:4 zeroes
        * tccr1a high byte zeroes
        * 16 us
      OCR1A = 0;
      OCR1B = 0;
      // Start tcount at 1
TCNT1 = 0x00;
      // Normal mode
      TCCR1A = 0x00;
      // enable overflow interrupt
TIMSK1 |= (1 << TOIE1);</pre>
      // ensure we start with the timer off
      turnoffTimer1();
void initTimer2()
      // phase correct with 1024 prescaler gets us a high enough max time // use OCR2A to set TOP (WCM 5) such that we interrupt as close to 2ms ^{\circ}
      // as possible
      // OCR2A = 16MHz/(2*1024*50Hz)
      , colling the choice 50Hz because 50Hz=20ms // CCR2A = 156.25, we can't have fractions so we use 156 CCR2A = 156;
      // OCR2B = 16MHz*(pulse width of the pulse
// OCR2B = 16MHz*(pulse width in ms)/(2*1024)
// 1ms = 8, 1.5ms = 12, 2ms = 16
       // start facing forward
      OCR2B = 12;
      // start TC2 at 0
      TCNT2 = 0x00;
      // phase corrected PWM mode with 1024 clock prescale TCCR2A |= (0 << COM2A1) | (0 << COM2A0) | (1 << COM2B1) | (0 << COM2B0) | (0 << WGM21) | (1 << WGM20); TCCR2B |= (1 << WGM22) | (1 << CS22) | (1 << CS21) | (1 << CS20);
* Magical Timer land
 * Prescaler value goes in TCCR1B
 * 0 - off

* 1 - no prescaling

* 2 - clock /8
 * 3 - clock /64
```

```
* 4 - clock /256 - 16us
* 5 - clock /1024 - 64us
* source -
* https://sites.google.com/site/qeewiki/books/avr-guide/timers-on-the-atmega328
*/

// convenience function to turn the timer off
void turnoffTimer1() { TCCRIB &= 0x00; }

// convenience function to turn the timer back on with a default prescaler
void turnonTimer1() { TCCRIB |= 0x05; }

// Reads from timer 1 counter
unsigned int TIM16-ReadTCNT1()
{

    unsigned char sreg;
    unsigned int i;
    // Save global interrupt flag
    sreg = SREG;
    // Disable interrupts
    cli();
    // Read TCNT1 into i
    i = TCNT1;
    // Restore global interrupt flag
    SREG = sreg;
    return i;
}

// Sets timer 1 counter
void TIM16-WriteTCNT1(unsigned int i)
{
    unsigned char sreg;
    // Save global interrupt flag
    sreg = SREG;
    // Disable interrupts
cli();
    // Set TCNT1 to i
    TCNT1 = i;
    // Restore global interrupt flag
    SREG = sreg;
}
```

Appendix H: ultrasonic.h

```
#ifndef JULTRASONIC.H.
#define JULTRASONIC.H.
#include "bit.macros.h"
#include "globals.h"
#include "pin.map.h"
// #include "robotlo.h"
#include "robotlo.h"
#include "timers.h"
#include <avr/io.h>
#include <avr/io.h>
#include <util/delay.h>

/*

* Ultrasonic sensor: A4 A5 (portc 4 5)
* Servo Motor: 3 (portd 3)
*/
void initUltrasonic();
void triggerUltrasonic();
unsigned int readUltrasonic();
#endif
```

Appendix H: ultrasonic.c

```
#include "ultrasonic.h"
  * Ultrasonic sensor functions
  * Sets the pins for ultrasonic sensor,

* then will setup the necessary timer 1

* to properly time the sensor
void initUltrasonic()
       // Trig on A5
setBit(DDRC, US_TRIG);
// Echo on A4
clearBit(DDRC, US_ECHO);
       clearBit(PORTC, US_TRIG);
clearBit(PORTC, US_ECHO);
       // setBit(PORTC, US_ECHO); // pull—up for echo
       initTimer1();
unsigned int readUltrasonic()
       // Trigger the sensor
triggerUltrasonic();
// Spin while we either timeout or wait
while (!TimerOverflow && !responseAvailable)
        unsigned int i = TIM16_ReadTCNT1();
       // 64 us per count in i
unsigned int result = ((i * 64) / 58);
       return result;
}
// Triggers ultrasonic sensor, then waits 60 ms vid triggerUltrasonic() \dot{}
       TimerOverflow = false;
setBit(PORIC, US_TRIG);
_delay_us(9);
clearBit(PORIC, US_TRIG);
// reset counter 1
// TIM16_WriteTCNT1(0);
// Delay while pulse is sent_delay_us(60);
```