Wiring colours harmonised.
New 3 sensor design.
Flash socket addded
Light meter added
V3.16
Encoder added
Stepper added
tft Touch\_CS move to pin 17
V3.1.7
orange button wire changed to white
Laser & flash pins changed
V3.18 added LCD, LED matrix & Button5

Note:-DO NOT use the GND pin on the EPS32 board, that is located between pins 19 & 21.

Transparent three legged sensors must be fitted with the flat surface at the rear and the little dome pointing over the board and towards

the laser. Connecting them incorrectly WILL destroy them.

Caution
To avoid sensor
damage, wire up the
rx modules BEFORE
plugging the
transparent senors
into them. Double
check wiring BEFORE
powering up the
board & ensure LEDs
light.

Then de-power the board and insert sensors ENSURING the sensor is fitted the correct way round.

BARE MINIMUM
In this configuration, all test data
will be set to computer screen only

Aduino IDE must be running on the PC with 'Serial Monitor optoin open.

