
BATTERIES AND SENSOR HOLDER




ASSEMBLY

- Solder two 3in wires to the SPST
- Run wires from Switch through the top of Sensor Holder and attach Switch to Sensor Holder(Glued here)
- Solder wire connecting positive battery terminals together. Do the same for negative terminals
- Solder 3in of wire to positive terminal of Battery Holder. Repeat for negative terminal



PARTS

- Sensor Holder 1 - Battery Holder 1 X - SPST Switch 1 - 1/8in Flat head screws 2 X - Female Dupont Connectors x 2 - 22 Gauge Wire (Red) 1 1/2ft X - 22 Gauge Wire(Black) 1 1/2ft X - Shrink Tubing 4in Х - PowerBoost Connector X 1



- Run the two wires from the Battery holder through the top of the Sensor holder
- Screw in battery Holder to top of Sensor Holder
- Solder red wire from PowerBoost Connector to positive terminal wire and black wire from PowerBoost Connector to negative battery terminal
- Protect batteries by covering Screws in Battery Holder with shrink tubing. Glue or tape down.