
7-1. Components on the Rear Case



7-2. Pre-requisite



7-3. Parts which must be changed after repair

BOM Description & part code	Image	Remarks
Backcover Outside tape [GH81-19575A]		Left items must be changed to the new one in case of disassemble the Back glass.

7-4. Disassembly

1 Store it in High Temp. Chamber. (Chamber Temp. 70°C ±5°C, Stand-by for 15 ±5mins) Remove the Backglass with AOD JIG.



2 Remove Rear Cover.





 Caution Be care of scratch.

> Remove all 15 points of Rear Screws 3

- Torque Value : 1.15kgf $\,\pm\,\,$ 7%



 Caution Be care of scratch.


> Remove 1 PBA screw. - Torque Value : 0.95kgf $\,\pm\,\,$ 7%



***** Caution Be care of Rear damage.


 Caution Be careful not to damage the PBA.

Remove the PBA and C to C FPCB and Batt Conn and COAXIAL CABLE And VT Camera, Macro Camera, Vokeh CAM



Remove WIDE/Ultra wide CAM connectors.

Aging chamber 75°C±5 10minute before CAM disassemble.



***** Caution

Be care of several kinds of damage at PBA and FPCB.

Caution

6

Be careful not to damage the Camera Module.

7 Detach RCV from Front Ass'y.



8 Detach Motor from Front Ass'y.



***** Caution

Be careful not to damage the RCV.

Caution


Be careful not to damage the Motor.

9

Remove octa conn, C to C FPCB and COAXIAL CABLE.



10 Detach the Sub PBA.



***** Caution

- 1) Be careful not to damage the octa conn, C to C FPCB and COAXIAL CABLE.
- 2) Be careful not to damage the PBA

Caution

Be careful not to damage the Sub PBA.

7-5. Assembly

1 Attach Sub PBA on Front Ass'y.

Assemble C to C FPCB and COAXIAL CABLE Assmble OCTA/ C to C Conn. and COAXIAL CABLE.






Caution
Be care of Sub PBA damage.


Caution

- 1) Be careful not to damage the C to C FPCB and Red COAXIAL CABLE.
- 2) Be careful not to damage the PBA

3 Attach Motor and Receiver in upper area.



Assemble the PBA and C to C FPCB and Batt Conn and COAXIAL CABLE and VT Camera/Macro Camera/Vokeh Cam.




Caution
Be care of damage each part.

- Caution
- 1) Be care of scratch CAM lens.
- 2) Check for each connector connection.

5

Screw insertion 1 Point.

- Torque Value : 1.1kgf ± 7%



6

Assemble Rear and screw insertion 15 point.

- Torque Value: 1.15 ±7%



Caution

Be care of PBA damage.

Caution

Be care of Rear damage.

7

changed to the new one Backcover Outsid tape.




8

Press the back glass using pressing jig and pad.

- Pressing force : 1N, Pressing time : 1 minute* SIM Tray must be separated before

pressing the backglass or the LCD.



Caution

Be care of damage each part.

***** Caution

Be care of scratch Rear cover.