

Fusion and FreeCAD shortcuts

Windows/Linux notation. Your configured FreeCAD keys come first; the complete Fusion reference follows. Fusion-only tools are not automatically available in FreeCAD.

Your FreeCAD setup

Command	Shortcut
Extrude / Pad	E
Fillet	F
Hole	H
Measure	I
Move / transform	M
Toggle visibility	V
Sketch: line	L
Sketch: rectangle	R
Sketch: circle	C
Sketch: dimension	D
Sketch: trim	T
Sketch: toggle construction	X
Sketch: offset	O
Sketch: project external geometry	P
Appearance	A
Recompute document	Ctrl+B
Macro manager	Shift+S
Redo	Ctrl+Y
New document	Ctrl+N
Open	Ctrl+O
Save	Ctrl+S
Save as	Ctrl+Shift+S
Undo	Ctrl+Z
Copy	Ctrl+C
Paste	Ctrl+V
Cut	Ctrl+X
Delete	Del
Close sketch	Shift+Esc
Fit view	Home
Show / hide Model panel	Ctrl+Alt+B
Show / hide Tasks panel	Ctrl+Right
Search tools	S

P projects external geometry while editing a sketch. Shift+Esc closes the sketch. Save As and the macro manager are FreeCAD equivalents, with different behavior from Fusion cloud recovery and add-ins.

Fusion reference

Documented default shortcuts, grouped by context. Mouse gestures and selection-dependent operations are included. Shortcuts may be intercepted while a text field is active.

Modeling and sketch

Command	Shortcut
Extrude	E
Hole	H
Press Pull	Q
Model Fillet	F
Move	M
Toggle Visibility	V
Display Component Colors	Shift+N
Model Toolbox	S
Appearance	A
Compute All	Ctrl+B (Windows) or Command+B (macOS)
Joint	J
As-built Joint	Shift+J
Line	L
2-point Rectangle	R
Center Diameter Circle	C
Trim	T
Offset	O
Measure	I
Project	P
Normal / Construction	X
Sketch Dimension	D
Sketch Coincident Constraint at Midpoint	Shift
Scripts and Add-ins	Shift+S
Window Selection	1
Freeform Selection	2
Paint Selection	3
Delete	Del

System

Command	Shortcut
New Design	Ctrl+N
Open	Ctrl+O
Save (Version)	Ctrl+S
Recovery Save	Ctrl+Shift+S
Cycle open document tabs	Ctrl+Tab
Show/Hide ViewCube	Ctrl+Alt+V
Show/Hide Browser	Ctrl+Alt+B
Show/Hide Comments	Ctrl+Alt+A
Show/Hide Text Commands	Ctrl+Alt+C
Show/Hide Navigation bar	Ctrl+Alt+N
Show/Hide Data Panel	Ctrl+Alt+P
Reset to Default Layout	Ctrl+Alt+R

Canvas and editing

Command	Shortcut
Pan	Hold Middle Mouse Button
Zoom	Roll Middle Mouse Button
Orbit	Hold Shift+Middle Mouse Button
Orbit around point	Hold Shift+Click+Middle Mouse Button
Undo	Ctrl+Z
Redo	Ctrl+Y
Copy	Ctrl+C
Paste	Ctrl+V
Cut	Ctrl+X

Direct Mesh Editing

Command	Shortcut
Expand to Face Group	Alt+G
Expand to Connected	Alt+C
Grow Selection	Shift+Up Arrow
Shrink Selection	Shift+Down Arrow
Invert	Alt+N

Form

Command	Shortcut
Toggle Box mode (Displays the control points of the T-Spline body; 1)	Alt+1
Toggle Box mode (2+)	Select a body, face, edge, or vertex and then press Alt+1
Toggle Control Frame mode (Displays the rounded T-Spline body with the control frame around it.; 1)	Alt+2
Toggle Control Frame mode (2+)	Select a body, face, edge, or vertex and then press Alt+2
Toggle Smooth mode (Displays the rounded shape of the T-Spline body.; 1)	Alt+3
Toggle Smooth mode (2+)	Select a body, face, edge, or vertex and then press Alt+3

Form

Command	Shortcut
Grow selection (Edges, Faces, and Vertices)	Shift+Up Arrow
Shrink selection (Edges, Faces, and Vertices)	Shift+Down Arrow
Loop selection (Faces)	Select a face then SHIFT-double-click an adjacent second face OR Select two adjacent faces then press Alt+P
Loop selection (Edges)	Double-click an edge OR Select an edge then press Alt+P
Loop selection (Vertices)	Select a vertex then hold SHIFT and double-click an adjacent second vertex OR Select two adjacent vertices then press Alt+P
Loop grow selection (Faces)	Select two adjacent faces then press Alt+O
Loop grow selection (Edges)	Select an edge then press Alt+O
Loop grow selection (Vertices)	Select two adjacent vertices then press Alt+O
Ring selection (Edges)	Select an edge then press Alt+L
Ring grow selection (Edges)	Select an edge then press Alt+K
Ring shrink selection (Edges)	Alt+J
Previous U (Edges, Faces, and Vertices)	Select one or more edges, faces, or vertices then press Alt+Left Arrow
Next U (Edges, Faces, and Vertices)	Alt+Right Arrow
Previous V (Edges, Faces, and Vertices)	Alt+Down Arrow
Next V (Edges, Faces, and Vertices)	Alt+Up Arrow
Range selection (Edges, Faces, and Vertices)	Alt+M
Invert selection (Edges, Faces, and Vertices)	Alt+N
Feature selection (Faces)	Select a face then press Alt+H

Form

Command	Shortcut
Extrude (Faces)	Select one or more faces then Alt+Drag
Extrude (Boundary edges)	Select one or more boundary edges then Alt+Drag
Extrude geometry and keep creases (Faces)	Select one or more faces with creased edges then Alt+Ctrl+Drag
Extrude geometry and keep creases (Boundary edges)	Select one or more boundary edges then Alt+Ctrl+Drag

Generative Design workspace

Command	Shortcut
New Generative Study	N
Study Settings	E
Structural Constraints	C
Structural Loads	L

Render workspace

Command	Shortcut
Appearance	A

Animation workspace

Command	Shortcut
Transform Components	M
Auto Explode All Levels	U
Manual Explode	E
View	Ctrl+R
Publish Video	P

Simulation workspace

Command	Shortcut
Ambient Temperature (e-cooling only)	A
DOF View	Ctrl+D
Fan (e-cooling only)	F
Force	F
Groups View	Ctrl+G
Model View	Ctrl+L
New Simulation Study	N
Results View	Ctrl+R
Settings	E
Structural Constraint	C
Structural Loads	L
Temperature Thresholds (e-cooling only)	T
Thermal Loads	H

Manufacture workspace

Command	Shortcut
Generate Toolpath	Ctrl+G
Duplicate	Ctrl+D
Show Log	Ctrl+L
Scripts and Add-Ins	Shift+S

Drawing workspace

Command	Shortcut
Projected View	P
Move	M
Delete	Delete
Center Mark	C
Dimension	D
Text	T
Balloon	B

Electronics workspace

Command	Shortcut
Activate command line	/
Add Hole	H
Add Text	T
Bus	B
Change	C
Copy	Ctrl+C
Delete	Delete
Dimension	D
DRC	Ctrl+D
ERC	Ctrl+E
Errors	E
Flip Board	F
Grid	G
Label	Shift+L
Manual Route	R
Move	M
Name	N
Net	R
New Device	Alt+Ctrl+3
New Footprint	Alt+Ctrl+2
New Symbol	Alt+Ctrl+1
Package 3D Create	Alt+Ctrl+4
Pad	O
Pad Array	Shift+O
PCB 3D View	Ctrl+3
Pin	P
Pin Array	Shift+P
Place Component	A
Redo	Ctrl+Y
Ripup	U
Ripup All Polygons	Alt+Shift+P
Route Diff Pair	Ctrl+R
Route Multi	Shift+R
Run Script	Alt+Shift+S
Run ULP	Shift+U
Shortcut Dialog	S
SMD	P
SMD Array	Shift+P
Stop	ESC

Command	Shortcut
Switch Sch Doc	Ctrl+1
Switch PCB Doc	Ctrl+2
Switch to Next Layer	Ctrl+Down Arrow
Switch to Previous Layer	Ctrl+Up Arrow
Undo	Ctrl+Z
Value	V
Via	Alt+V
Zoom to Fit	F6

Autodesk Assistant

Command	Shortcut
Open / close Assistant (Windows)	Shift+H
Assistant zoom in	Ctrl++
Assistant zoom out	Ctrl+-

Switch workspaces

Command	Shortcut
Previous workspace	Ctrl+[
Next workspace	Ctrl+]

Source: Autodesk Fusion keyboard shortcuts reference. Official reference:
help.autodesk.com/cloudhelp/ENU/Fusion-GetStarted/files/GUID-F0491540-0324-470A-B651-2238D0EFAC30.htm