

Command		Key Combinations	
Extrude		E	
Hole		H	
Press Pull		Q	
Fillet		F	
Move		M	
Toggle Visibility		V	
Toggle Component Color Cycling		Shift + N	
Model Toolbox		S	
Appearance		A	
Compute All		Ctrl + B (Windows) or Command + B (Mac)	
Joint		J	
As-built Joint		Shift + J	
Line		L	
2-point Rectangle		R	
Center Diameter Circle		C	
Trim		T	
Offset		O	
Measure		I	
Project		P	
Normal / Construction		X	
Sketch Dimension		D	
Scripts and Add-ins		Shift + S	
Window Selection		1	
Freeform Selection		2	
Paint Selection		3	
Delete		Del	
System Keyboard Shortcuts		Windows Key Combinations	Mac Key Combinations
Create Version		Ctrl + S	Command + S
Recovery Save		Ctrl + Shift + S	Command + Shift + S
Canvas Selection	Windows Key Combinations		Mac Key Combinations
Pan	Hold Middle Mouse Button		Hold Middle Mouse Button

Canvas Selection	Windows Key Combinations	Mac Key Combinations
Zoom	Roll Middle Mouse Button	Roll Middle Mouse Button
Orbit	Hold Shift + Hold Middle Mouse Button	Hold Shift + Hold Middle Mouse Button
Orbit around point	Hold Shift + Click then Hold Middle Mouse Button	Hold Shift + Click then Hold Middle Mouse Button
Undo	Ctrl + Z	Command + Z
Redo	Ctrl + Y	Command + Y
Copy	Ctrl + C	Command + C
Paste	Ctrl + V	Command + V
Cut	Ctrl + X	Command + X
Sculpt Workspace Selection	Windows Key Combinations	Mac Key Combinations
Grow selection	Shift + Up Arrow	Shift + Up Arrow
Shrink selection	Shift + Down Arrow	Shift + Down Arrow
Loop selection	Alt + P	Control + P
Loop grow selection	Alt + O	Control + O
Ring selection	Alt + L	Control + L
Ring grow selection	Alt + K	Control + K
Ring shrink selection	Alt + J	Control + J
Previous U	Alt + Left Arrow	Control + Command + Left Arrow
Next U	Alt + Right Arrow	Control + Command + Right Arrow
Previous V	Alt + Down Arrow	Control + Command + Down Arrow
Next V	Alt + Up Arrow	Control + Command + Up Arrow
Range selection	Alt + M	Command + M
Invert selection	Alt + N	Command + N
Toggle box mode	Alt + 1	Control + 1
Toggle control frame mode	Alt + 2	Control + 2
Toggle smooth mode	Alt + 3	Control + 3
Select edge ring	Double-click an edge	Double-click an edge
Select face ring	Select two faces then double-click a third face	Select two faces then double-click a third face

Edit Form Command	Windows Key Combinations	Mac Key Combinations
Add geometry	Alt + Drag	Alt + Drag
Add geometry and keep creases	Alt + Ctrl + Drag	Alt + Command + Drag
Render Workspace Command	Windows Key Combinations	Mac Key Combinations
Appearance	A	A
Animate Workspace Command	Windows Key Combinations	Mac Key Combinations
Transform Components	M	M
Auto Explode All Levels	U	U
Manual Explode	E	E
View	U	U
Publish Video	P	P
Simulate Workspace Command	Windows Key Combinations	Mac Key Combinations
New Simulation Study	N	N
Structural Constraint	C	C
Structural Loads	L	L
Force	F	F
Model View	Ctrl + L	Command + L
DOF View	Ctrl + D	Command + D
Groups View	Ctrl + G	Command + G
Results View	Ctrl + R	Command + R
Settings	E	E
Drawing Workspace Command	Windows Key Combinations	Mac Key Combinations
Projected View	P	P
Move	M	M
Delete	Delete	Delete
Center Mark	C	C
Dimension	D	D
Text	T	T
Balloon	B	B

CAM Workspace Command	Windows Key Combinations	Mac Key Combinations
Generate Toolpath	Ctrl + G	Command + G
Duplicate	Ctrl + D	Command + D
Show Log	Ctrl + L	Command + L
Scripts and Add-Ins	Shift + S	Shift + S

Shortcuts for switching workspaces

You can now switch workspaces with CTRL + Leftbracket and CTRL + Rightbracket key combos. This will take you through the next and previous workspace in the order it is listed in the workspace switcher.

Current Fusion shortcuts - complete reference index

Windows/Linux key notation. Some Fusion-only functions have no FreeCAD equivalent. Source: Autodesk Fusion keyboard shortcuts reference.

Context	Command	Key / gesture
Modeling and sketch	Extrude	E
Modeling and sketch	Hole	H
Modeling and sketch	Press Pull	Q
Modeling and sketch	Model Fillet	F
Modeling and sketch	Move	M
Modeling and sketch	Toggle Visibility	V
Modeling and sketch	Display Component Colors	Shift+N
Modeling and sketch	Model Toolbox	S
Modeling and sketch	Appearance	A
Modeling and sketch	Compute All	Ctrl+B (Windows) or Command+B (macOS)
Modeling and sketch	Joint	J
Modeling and sketch	As-built Joint	Shift+J
Modeling and sketch	Line	L
Modeling and sketch	2-point Rectangle	R
Modeling and sketch	Center Diameter Circle	C
Modeling and sketch	Trim	T
Modeling and sketch	Offset	O
Modeling and sketch	Measure	I
Modeling and sketch	Project	P
Modeling and sketch	Normal / Construction	X
Modeling and sketch	Sketch Dimension	D
Modeling and sketch	Sketch Coincident Constraint at Midpoint	Shift
Modeling and sketch	Scripts and Add-ins	Shift+S
Modeling and sketch	Window Selection	1
Modeling and sketch	Freeform Selection	2
Modeling and sketch	Paint Selection	3
Modeling and sketch	Delete	Del
System	New Design	Ctrl+N
System	Open	Ctrl+O
System	Save (Version)	Ctrl+S
System	Recovery Save	Ctrl+Shift+S
System	Cycle open document tabs	Ctrl+Tab
System	Show/Hide ViewCube	Ctrl+Alt+V
System	Show/Hide Browser	Ctrl+Alt+B
System	Show/Hide Comments	Ctrl+Alt+A
System	Show/Hide Text Commands	Ctrl+Alt+C
System	Show/Hide Navigation bar	Ctrl+Alt+N
System	Show/Hide Data Panel	Ctrl+Alt+P

Context	Command	Key / gesture
System	Reset to Default Layout	Ctrl+Alt+R
Modeling and sketch	Pan	Hold Middle Mouse Button
Modeling and sketch	Zoom	Roll Middle Mouse Button
Modeling and sketch	Orbit	Hold Shift+Middle Mouse Button
Modeling and sketch	Orbit around point	Hold Shift+Click+Middle Mouse Button
Modeling and sketch	Undo	Ctrl+Z
Modeling and sketch	Redo	Ctrl+Y
Modeling and sketch	Copy	Ctrl+C
Modeling and sketch	Paste	Ctrl+V
Modeling and sketch	Cut	Ctrl+X
Direct Mesh Editing	Expand to Face Group	Alt+G
Direct Mesh Editing	Expand to Connected	Alt+C
Direct Mesh Editing	Grow Selection	Shift+Up Arrow
Direct Mesh Editing	Shrink Selection	Shift+Down Arrow
Direct Mesh Editing	Invert	Alt+N
Form	Toggle Box mode	Alt+1
Form	Toggle Box mode	Select a body, face, edge, or vertex and then press Alt+1
Form	Toggle Control Frame mode	Alt+2
Form	Toggle Control Frame mode	Select a body, face, edge, or vertex and then press Alt+2
Form	Toggle Smooth mode	Alt+3
Form	Toggle Smooth mode	Select a body, face, edge, or vertex and then press Alt+3
Form	Grow selection	Shift+Up Arrow
Form	Shrink selection	Shift+Down Arrow
Form	Loop selection	Select a face then SHIFT-double-click an adjacent second face OR Select two adjacent faces then press Alt+P
Form	Loop selection	Double-click an edge OR Select an edge then press Alt+P
Form	Loop selection	Select a vertex then hold SHIFT and double-click an adjacent second vertex OR Select two adjacent vertices then press Alt+P
Form	Loop grow selection	Select two adjacent faces then press Alt+O
Form	Loop grow selection	Select an edge then press Alt+O
Form	Loop grow selection	Select two adjacent vertices then press Alt+O
Form	Ring selection	Select an edge then press Alt+L
Form	Ring grow selection	Select an edge then press Alt+K
Form	Ring shrink selection	Alt+J
Form	Previous U	Select one or more edges, faces, or vertices then press Alt+Left Arrow
Form	Next U	Alt+Right Arrow
Form	Previous V	Alt+Down Arrow
Form	Next V	Alt+Up Arrow
Form	Range selection	Alt+M
Form	Invert selection	Alt+N

Context	Command	Key / gesture
Form	Feature selection	Select a face then press Alt+H
Form	Extrude	Select one or more faces then Alt+Drag
Form	Extrude	Select one or more boundary edges then Alt+Drag
Form	Extrude geometry and keep creases	Select one or more faces with creased edges then Alt+Ctrl+Drag
Form	Extrude geometry and keep creases	Select one or more boundary edges then Alt+Ctrl+Drag
Generative Design workspace	New Generative Study	N
Generative Design workspace	Study Settings	E
Generative Design workspace	Structural Constraints	C
Generative Design workspace	Structural Loads	L
Render workspace	Appearance	A
Animation workspace	Transform Components	M
Animation workspace	Auto Explode All Levels	U
Animation workspace	Manual Explode	E
Animation workspace	View	Ctrl+R
Animation workspace	Publish Video	P
Simulation workspace	Ambient Temperature (e-cooling only)	A
Simulation workspace	DOF View	Ctrl+D
Simulation workspace	Fan (e-cooling only)	F
Simulation workspace	Force	F
Simulation workspace	Groups View	Ctrl+G
Simulation workspace	Model View	Ctrl+L
Simulation workspace	New Simulation Study	N
Simulation workspace	Results View	Ctrl+R
Simulation workspace	Settings	E
Simulation workspace	Structural Constraint	C
Simulation workspace	Structural Loads	L
Simulation workspace	Temperature Thresholds (e-cooling only)	T
Simulation workspace	Thermal Loads	H
Manufacture workspace	Generate Toolpath	Ctrl+G
Manufacture workspace	Duplicate	Ctrl+D
Manufacture workspace	Show Log	Ctrl+L
Manufacture workspace	Scripts and Add-Ins	Shift+S
Drawing workspace	Projected View	P
Drawing workspace	Move	M
Drawing workspace	Delete	Delete
Drawing workspace	Center Mark	C
Drawing workspace	Dimension	D
Drawing workspace	Text	T
Drawing workspace	Balloon	B
Electronics workspace	Activate command line	/

Context	Command	Key / gesture
Electronics workspace	Add Hole	H
Electronics workspace	Add Text	T
Electronics workspace	Bus	B
Electronics workspace	Change	C
Electronics workspace	Copy	Ctrl+C
Electronics workspace	Delete	Delete
Electronics workspace	Dimension	D
Electronics workspace	DRC	Ctrl+D
Electronics workspace	ERC	Ctrl+E
Electronics workspace	Errors	E
Electronics workspace	Flip Board	F
Electronics workspace	Grid	G
Electronics workspace	Label	Shift+L
Electronics workspace	Manual Route	R
Electronics workspace	Move	M
Electronics workspace	Name	N
Electronics workspace	Net	R
Electronics workspace	New Device	Alt+Ctrl+3
Electronics workspace	New Footprint	Alt+Ctrl+2
Electronics workspace	New Symbol	Alt+Ctrl+1
Electronics workspace	Package 3D Create	Alt+Ctrl+4
Electronics workspace	Pad	O
Electronics workspace	Pad Array	Shift+O
Electronics workspace	PCB 3D View	Ctrl+3
Electronics workspace	Pin	P
Electronics workspace	Pin Array	Shift+P
Electronics workspace	Place Component	A
Electronics workspace	Redo	Ctrl+Y
Electronics workspace	Ripup	U
Electronics workspace	Ripup All Polygons	Alt+Shift+P
Electronics workspace	Route Diff Pair	Ctrl+R
Electronics workspace	Route Multi	Shift+R
Electronics workspace	Run Script	Alt+Shift+S
Electronics workspace	Run ULP	Shift+U
Electronics workspace	Shortcut Dialog	S
Electronics workspace	SMD	P
Electronics workspace	SMD Array	Shift+P
Electronics workspace	Stop	ESC
Electronics workspace	Switch Sch Doc	Ctrl+1
Electronics workspace	Switch PCB Doc	Ctrl+2
Electronics workspace	Switch to Next Layer	Ctrl+Down Arrow

Context	Command	Key / gesture
Electronics workspace	Switch to Previous Layer	Ctrl+Up Arrow
Electronics workspace	Undo	Ctrl+Z
Electronics workspace	Value	V
Electronics workspace	Via	Alt+V
Electronics workspace	Zoom to Fit	F6
Autodesk Assistant	Assistant toggle	Shift+H
Autodesk Assistant	Assistant zoom in	Ctrl++
Autodesk Assistant	Assistant zoom out	Ctrl+-
Workspaces	Previous workspace	Ctrl+[
Workspaces	Next workspace	Ctrl+]

Your configured FreeCAD shortcuts

Key	FreeCAD command
E	PartDesign_Pad
F	PartDesign_Fillet
H	PartDesign_Hole
I	Std_Measure
M	Std_TransformManip
V	Std_ToggleVisibility
L	Sketcher_CreateLine
R	Sketcher_CreateRectangle
C	Sketcher_CreateCircle
D	Sketcher_ConstrainDistance
T	Sketcher_Trimming
X	Sketcher_ToggleConstruction
O	Sketcher_Offset
P	Sketcher_Projection
A	Std_SetAppearance
Ctrl+B	Std_Refresh
Shift+S	Std_DlgMacroExecute
Ctrl+Y	Std_Redo
Ctrl+N	Std_New
Ctrl+O	Std_Open
Ctrl+S	Std_Save
Ctrl+Shift+S	Std_SaveAs
Ctrl+Z	Std_Undo
Ctrl+C	Std_Copy
Ctrl+V	Std_Paste
Ctrl+X	Std_Cut
Del	Std_Delete

Key	FreeCAD command
Shift+Esc	Sketcher_LeaveSketch
Home	Std_ViewFitAll
Ctrl+Alt+B	Std_DockOverlayToggleLeft
Ctrl+Right	Std_DockOverlayToggleRight
S	Search tools