

Z axis configuration for all systems

File Device Help

Connected to: T825 #00449077

Status Input and motor settings Advanced settings

Control mode: Serial/I²C/USB

Serial

Baud rate: 9600

Device number: 14

☐ Alternative device number: 0

☐ Enable 14-bit device number

Response delay: 0 μ s

☐ Enable command timeout: 1.000 s

☐ Enable CRC for commands

☐ Enable CRC for responses

☐ Enable 7-bit responses

Encoder

Prescaler: 1

Postscaler: 1

☐ Enable unbounded position control

Input conditioning

☒ Enable input averaging

Input hysteresis: 0

RC and analog scaling

☐ Invert input direction [Learn...](#)

	Input	Target
Maximum:	4095	200
Neutral max:	2080	
Neutral min:	2015	
Minimum:	0	-200

Scaling degree: 1 - Linear

Motor

☐ Invert motor direction

Max speed: 10000000 1000.0000 pulses/s

Starting speed: 100000 10.0000 pulses/s

Max acceleration: 40000 400.00 pulses/s²

Max deceleration: 40000 400.00 pulses/s²

☒ Use max acceleration limit for deceleration

Step mode: Full step

Current limit: 544 mA

Decay mode: Slow

De-energize Resume Driving.

Apply settings

Configuration for X and Y rails on three axis system

Pololu Tic Control Center

File Device Help

Connected to: T825 #00473556

Status Input and motor settings Advanced settings

Control mode: Serial/PC/USB

Serial

Baud rate: 9600 ☐ Enable command timeout: 1.000 s

Device number: 14 ☐ Enable CRC for commands

☐ Alternative device number: 0 ☐ Enable CRC for responses

☐ Enable 14-bit device number ☐ Enable 7-bit responses

Response delay: 0 μ s

Encoder

Prescaler: 1

Postscaler: 1

☐ Enable unbounded position control

RC and analog scaling

☐ Invert input direction [Learn...](#)

	Input	Target
Maximum:	4095	200
Neutral max:	2080	
Neutral min:	2015	
Minimum:	0	-200

Scaling degree: 1 - Linear

Motor

☐ Invert motor direction

Max speed: 10000000 1000.0000 pulses/s

Starting speed: 100000 10.0000 pulses/s

Max acceleration: 40000 400.00 pulses/s²

Max deceleration: 40000 400.00 pulses/s²

☒ Use max acceleration limit for deceleration

Step mode: Full step

Current limit: 544 mA

Decay mode: Mixed

De-energize Resume Driving. Apply settings

Endstop Configuration for all motors

FileDeviceHelp

Connected to: T825 #00473556

StatusInput and motor settingsAdvanced settings

Pin configuration

SCL: Default

☐ Pull-up

☐ Active high

☐ Analog

SDA/AN: Default

☐ Pull-up

☐ Active high

☐ Analog

TX: Default

(always pulled up)

☐ Active high

☐ Analog

RX: Default

(always pulled up)

☐ Active high

☐ Analog

RC: Limit switch reverse

(always pulled down)

☐ Active high

Soft error response

☐ De-energize

☐ Halt and hold

☒ Decelerate to hold

☐ Go to position: 0

☐ Use different current limit during soft error:

544 mA

Miscellaneous

☐ Disable safe start

☐ Ignore ERR line high

☒ Automatically clear driver errors

☐ Never sleep (ignore USB suspend)

VIN measurement calibration: 0

Homing

☐ Enable automatic homing

Automatic homing direction: Reverse

Homing speed towards: 500000 50.0000 pulses/s

Homing speed away: 500000 50.0000 pulses/s

De-energize

Resume

Driving...

Apply settings

Servo Configuration - only modify “Min” and “Max” for the channel you are using

Pololu Maestro Control Center

File Device Edit Help

Connected to: #00457781 Firmware version: 1.04 Error code: 0x0000

Status Errors Channel Settings Serial Settings Sequence Script

#	Name	Mode	Rate (Hz)	Min	Max	On startup or error:	Speed	Acceleration	8-bit neutral	8-bit range (+/-)	
0		Servo	50	64	3280	Off	992.00	0	0	1500.00	476.25
1		Servo	50	992	2000	Off	992.00	0	0	1500.00	476.25
2		Servo	50	992	2000	Off	992.00	0	0	1500.00	476.25
3		Servo	50	992	2000	Off	992.00	0	0	1500.00	476.25
4		Servo	50	992	2000	Off	992.00	0	0	1500.00	476.25
5		Servo	50	992	2000	Off	992.00	0	0	1500.00	476.25

Advanced Pulse Control

Servos available: 6

Period (ms): 20

Save Frame 0 Apply Settings