


Z axis assembly and X axis assembly







Left plastic seat 1pcs
X motor assemble 1pcs
Linear bearing 2pcs
Hexagon screw M3*20 3pcs
Screw PM3*18 2pcs
Hexagon nut M3 2pcs
Threaded Screw nut 1pcs




Note:The motor socket is alighned with the bottom of left plastic seat

Step 3-3



Parts:


Right plastic seat 1pcs
Linear bearing 2pcs
Screw PM3*18 2pcs
Hexagon screw M3*20 1pcs
Hexagon nut M3 2pcs
Threaded screw nut 1pcs
Frange bearing 2pcs




Note:Don't twist the screw too tight keep bearing rotates freely (These combination are well completed in upgraded version)




Left plasite seat assemble 1pcs
Right plastic seat assemble 1pcs
Frame unit M 2pcs
Frame unit R 2pcs
Screw PM3*18 6pcs
Hexagon nut M3 6pcs
X motor cable 1pcs





Step 3-5




Parts:
U bracket 1pcs
Hexagon screw M4*20 2pcs
Hexagon nut M4 6pcs







Frame unit N 2pcs
Hexagon screw M3*30 2pcs
Screw KA2*12 2pcs
Hexagon nut M3 2pcs
Z axis end stop 1pcs









Frame unit 0 1pcs Hexagon screw M4*16 2pcs screw KA2*12 2pcs X axis end stop 1pcs

