

PROCESS NOTES

*.GTL - TOP LAYER GERBER DATA

- 1) INSTALL PEM NUTS AS SHOWN
- 2) SOLDER PASTE ON PADS OF PS1 MUST BE 0.010in TO 0.012in THK

